

IFD6500

Instruction Sheet

USB/RS-485 Communication Interface

2014-04-29



5011661305-TUS5




Warning

- EN **IFD6500 is an OPEN-TYPE device. It should be installed in a control cabinet free of airborne dust, humidity, electric shock and vibration. To prevent non-maintenance staff from operating IFD6500, or to prevent an accident from damaging IFD6500, the control cabinet in which IFD6500 is installed should be equipped with a safeguard. For example, the control cabinet in which IFD6500 is installed can be unlocked with a special tool or key.**
- EN **DO NOT connect AC power to any of I/O terminals, otherwise serious damage may occur. Please check all wiring again before IFD6500 is powered up. After IFD6500 is disconnected, Do NOT touch any terminals in a minute. Make sure that the ground terminal on IFD6500 is correctly grounded in order to prevent electromagnetic interference.**
- FR **IFD6500 est un module OUVERT. Il doit être installé que dans une enceinte protectrice (boîtier, armoire, etc.) saine, dépourvue de poussière, d'humidité, de vibrations et hors d'atteinte des chocs électriques. La protection doit éviter que les personnes non habilitées à la maintenance puissent accéder à l'appareil (par exemple, une clé ou un outil doivent être nécessaires pour ouvrir la protection).**
- FR **Ne pas appliquer la tension secteur sur les bornes d'entrées/Sorties, ou l'appareil IFD6500 pourra être endommagé. Merci de vérifier encore une fois le câblage avant la mise sous tension du IFD6500. Lors de la déconnexion de l'appareil, ne pas toucher les connecteurs dans la minute suivante. Vérifier que la terre est bien reliée au connecteur de terre afin d'éviter toute interférence électromagnétique.**

Introduction

IFD6500 is a convenient RS-485-to-USB converter, which does not require external power-supply and complex setting process. It supports baud rate from 75 to 115.2kbps and auto switching direction of data transmission. In addition, it adopts RJ-45 in RS-485 connector for users to wire conveniently. And its tiny dimension, handy use of plug-and-play and hot-swap provide more conveniences for connecting all DELTA IABU products to your PC. Applicable Models: All DELTA IABU products.


Application & Dimension



Specifications

Power supply	No external power is needed
Power consumption	0.4W
Isolated voltage	2,500VDC
Baud rate	75, 150, 300, 600, 1,200, 2,400, 4,800, 9,600, 19,200, 38,400, 57,600, 115,200 bps
RS-485 connector	RJ-45
USB connector	A type (plug)
Compatibility	Full compliance with USB V2.0 specification
Max. cable length	RS-485 Communication Port: 100 m
Support RS-485 half-duplex transmission	

RJ-45



PIN	Description	PIN	Description
1	Reserved	5	SG-
2	Reserved	6	Reserved
3	Reserved	7	Reserved
4	SG+	8	Reserved

Preparations before Driver Installation

Please extract the driver file by following steps. You could find driver file in the CD supplied with IFD6500.

Note: DO NOT connect IFD6500 to PC before extracting the driver file.

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5
You should have a folder marked SiLabs under drive C.

Driver Installation

After connecting IFD6500 to PC, please install driver by following steps.

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5
Repeat Step 1 to Step 4 to complete COM PORT setting.

Browse and select directory, or enter C:\SiLabs\MCU\CP210x\WIN

LED Display

- Steady Green LED ON: power is ON.
- Blinking orange LED: data is transmitting.