


Drive parameters must be set

I59 [Comm. Prot]: 0 - Modbus-RTU
I60 [Inv. Number]: 1~250
I61 [Baud-rate]: 3 (9,600 bps as Factory default)
I62 [Lost Mode]: 0 - No action
I63 [Time-Out]: 1.0 sec
DRV [Drive mode]: 3(RS485)
FRQ [Freq. mode]: 7(RS485)
////////////////////////////////

Config Com2 as Modbus-RTU,9600,8,N,1




Slave Station Number setting




Slave address settings

Read:
D1480 = Output Current 0.1 A
D1481 = Output Frequency 0.01 Hz
D1482 = Output Voltage 0.1 V
D1483 = DC Link Voltage 0.1 V
D1484 = Output Power 0.1 kW
D1486 = Inverter Status

Write:
D1496 = Freq. Reference 0.01 Hz
D1497 = Run Command, example: D1497 = 2 Forward Run
D1498 = Acceleration Time 0.1 sec
D1499 = Deceleration Time 0.1 sec



Enable / Disable the Slave ID#
for example, if M1360 = OFF, ID 1 is Disabled



M1392 = Error Flag for ID 1 (ON = normal; OFF = error)

