



Config Com2 as Modbus-RTU,9600,8,N,1



Slave Station Number setting  
Altivar1: station2  
Altivar2: station4  
Altivar3: station6




Slave address settings  
Read:  
D1480, D1512, D1544 = Status word  
D1481, D1513, D1545 = Output frequency applied to the motor  
D1482, D1514, D1546 = Frequency reference before ramp  
D1483, D1515, D1547 = Current in the motor  
Write:  
D1496, D1528, D1560 = High speed  
D1497, D1529, D1561 = Low speed



Enable / Disable the Slave ID#  
for example, if M1360 = OFF, ID 1 is Disabled


54



Start Modbus Link

M1392 = Error Flag for ID 1 (ON = normal; OFF = error)

59



62