

ProNet CANOpen User's Manual

(Version: V1.04)



ESTUN AUTOMATION TECHNOLOGY CO., LTD

— Total Solution Supplier

—Contents—

Chapter 1 Brief introduction	2
1.1 CAN main files	2
1.2 Terms and abbreviations	2
1.3 Brief introduction	3
Chapter 2 Cabling and wiring	4
Chapter 3 CANopen communication	0
3.1 CAN identifier list	0
3.2 SDO	2
3.3 PDO	4
3.4 SYNC message	12
3.5 Emergency message	13
3.6 HEARTBEAT message	15
3.7 Network management (NMT service)	16
Chapter 4 Conversion factors(factor group)	18
4.1 Related parameters	19
4.2 Position factor	19
4.3 Velocity factor	21
4.4 Acceleration factor	22
Chapter 5 Position control function	24
Chapter 6 Device control	28
6.1 State diagram (State machine)	28
6.2 Relevant parameters of device control	29
6.2.1 Controlword	29
6.2.2 Statusword	30
6.2.3 Shutdown_option_code	32
6.2.4 Disable_operation_option_code	33
6.2.5 Quick_stop_option_code	33
6.2.6 Halt_option_code	34
6.2.7 Fault_reaction_option_code	34
Chapter 7 Control mode	35
7.1 Relevant parameter of control mode	35
7.1.1 Modes_of_operation	35
7.1.2 Modes_of_operation_display	36
7.2 Homing mode	36
7.2.1 Control word of homing mode	36
7.2.2 Status word of homing mode	36
7.2.3 Relevant parameter of homing mode	37
7.2.4 Homing sequences	39
7.3 Profile velocity mode	42
7.3.1 Control word of profile velocity mode	42
7.3.2 Status word of velocity mode	42
7.3.3 Relevant parameters of profile velocity mode	43
7.4 Profile position mode	46

7.4.1 Control word of profile position mode.....	46
7.4.2 Status word of profile position mode	46
7.4.3 Revelant parameters of profile position mode.....	47
7.4.4 Function Description.....	49
7.5 Interpolation position mode.....	52
7.5.1 Control word of interpolation position mode.....	52
7.5.2 Status word of interpolation position mode	52
7.5.3 Parameters of position interpolation control.....	52
7.5.4 Function description.....	55
Chapter 8 Parameters of the CAN interface	56
Chapter 9 CAN communication example.....	57
9.1 SDO configuration.....	57
9.2 PDO Configuration	57
9.3 Profile Position Mode	58
9.4 Interplate Position Mode	59
9.5 Homing	60
Chapter 10 Other function	61
10.1 Bus input	61
10.2 Dummy object	62
Appendix Object dictionary	63

Chapter 1 Brief introduction

1.1 CAN main files

Document Name	Source
CiA DS 301 V 4.01: CANopen Communication Profile for Industrial Systems - based on CAL	CiA
CiA DSP 402 V 2.0: CANopen Device Profile	CiA

1.2 Terms and abbreviations

CAN	Controller Area Network
CiA	CAN in Automation International Users and Manufacturers Group.
COB	Communication Object (CAN message). A unit of transportation in a CAN network. Data must be sent across a network inside a COB. The COB itself is part of the CAN message frame.
EDS	Electronic Data Sheet. A node-specific ASCII-format file required when configuring the CAN network. The EDS file contains general information on the node and its dictionary objects (parameters).
LMT	Layer Management. One of the service elements of the CAN Application Layer in the CAN Reference Model. It serves to configure parameters for each layer in the CAN Reference Model.
NMT	Network Management. One of the service elements of the CAN Application Layer in the CAN Reference Model. It performs initialization, configuration and error handling on a CAN network.
OD	A local storage of all Communication Objects (COB) recognized by a device.
Parameter	A parameter is an operating instruction for the drive. Parameters can be read and programmed with the drive control panel.
PDO	Process Data Object; a type of COB. Used for transmitting time-critical data, such as control commands, references and actual values.
RO	Denotes read-only access.
RW	Denotes read/write access.
SDO	Service Data Object; a type of COB. Used for transmitting non-time critical data, such as parameters.

1.3 Brief introduction

CANopen is a higher-layer protocol based on the CAN (Control Area Network) serial bus system and the CAL (CAN Application Layer). CANopen assumes that the hardware of the connected device has a CAN transceiver and a CAN controller as specified in ISO 11898.

The CANopen Communication Profile, CiA DS-301, includes both cyclic and event-driven communication, which makes it possible to reduce the bus load to minimum while still maintaining extremely short reaction times. High communication performance can be achieved at relatively low baud rates, thus reducing EMC problems and cable costs.

CANopen device profiles define both direct access to drive parameter and time-critical process data communication. The NCAN-02 fulfils CiA (CAN in Automation) standard DSP-402 (Drives and Motion Control), supporting the 'Manufacturer Specific' operating mode only.

The physical medium of CANopen is a differentially-driven two-wire bus line with common return according to ISO 11898. The maximum length of the bus is limited by the communication speed as follows:

Baud Rate	Max. Bus Length
1M bit/s	25 m
500k bit/s	100 m
250k bit/s	250 m
125k bit/s	500 m
100k bit/s	600 m
50k bit/s	1000 m

The maximum theoretical number of nodes is 127. However, in practice, the maximum number depends on the capabilities of the CAN transceivers used.

Further information can be obtained from the CAN in Automation International Users and Manufacturers Group (www.can-cia.de).

Chapter 2 Cabling and wiring

•The layout of CN3 terminal

Pin number	Name	Function
1	—	Reserved
2	—	
3	485+	RS-485 communication terminal
4	ISO_GND	Isolated GND
5	ISO_GND	
6	485-	RS-485 communication terminal
7	CANH	CAN communication terminal
8	CANL	CAN communication terminal

Note: Do not short terminal 1 and 2 of CN3


• The layout of CN4 terminal

Pin number	Name	Function
1	—	Reserved
2	—	
3	485+	RS-485 communication terminal
4	ISO_GND	Isolated GND
5	ISO_GND	
6	485-	RS-485 communication terminal
7	CANH	CAN communication terminal
8	CANL	CAN communication terminal

CN3 is always the input terminal of communication cable and CN4 is always the output terminal of communication cable. (If connection to another communication node is necessary, the cable will connect CN4 to next communication node. If not, a terminal resistor could be applied at CN4). When multiple ProNet devices are connected, it is forbidden to connect the CN3 terminals of different drives directly.

For example, a network is composed of one PLC, three ProNet drives called A, B and C. The cabling network is as below:
 PLC → CN3 of drive A, CN4 of drive A → CN3 of drive B, CN4 of drive B → CN3 of drive C, CN4 of drive C → 120Ω resistor.

The two ends of the CAN cable have to be terminated by a resistor of 120Ω (1%, 1/4W) as below.



Please select the bus cable with double twisted pair cables and shielding layer, one pair for connecting CAN-L and CAN-H, another pair for grounding.

Chapter 3 CANopen communication

CAL supplies all network management service and message transferring protocol with defining the content of object or type of object for communication. It defines how instead of what, which is the strength of CANopen.

CANopen is developed based on CAL. It applies CAL protocol subsets for communication and service and creates a solution to DCS. CANopen could freely extend the node function to simplicity or complex while the network nodes are accessible and available to each other.

The key concept of CANopen is object dictionary. This way of object description is also applied to other fieldbus system like Probus and Interbus-S. CANopen communication could access to all the parameter of drivers through object dictionary. Please notice object dictionary is not one part of CAL, instead of which it is realized in CANopen.

CANopen communication defines several types of objects as below...

Abbreviation	Full Spell	Description
SDO	Service Data Object	Used for normal parameterization of the servo controller
PDO	Process Data Object	Fast exchange of process data (e.g. velocity actual value) possible.
SYNC	Synchronization Message	Synchronization of several CAN nodes
EMCY	Emergency Message	Used to transmit error messages of the servo controller.
NMT	Network Management	Used for network services. For example usercan act on all controllers at the same time via this object type.
Heartbeat	Error Control Protocol	Used for observing all nodes by cyclic messages.

CAN employs data frames for transferring data between the host (controller) and the nodes on the bus. The following figure presents the structure of the data frame.

Start of frame	Arbitration field		Control field	Date field	Cyclical redundancy check	Acknowledged field	End of frame
	COB-ID	RTR					
1BIT	1 OR 29 BITS	1BIT	6BITS	0~8BYTES	16BITS	2BITS	7BITS

Our drivers doesn't support remote frame currently. The detail of COB-ID is as below.

Function code				Node ID						
10	9	8	7	6	5	4	3	2	1	0

3.1 CAN identifier list

Object	COB-ID bit10~7 (binary)	COB-ID (hex)	Index in OD
NMT	0000	000 _h	—
SYNC	0001	080 _h	1005 _h 、1006 _h 、1007 _h
TIME STAMP	0010	100 _h	1012 _h 、1013 _h

EMCY	0001	081 _h ~ 0FF _h	1024 _h 、1015 _h
PDO1 (transmit)	0011	181 _h ~ 1FF _h	1800 _h
PDO1 (receive)	0100	201 _h ~ 27F _h	1400 _h
PDO2 (transmit)	0101	281 _h ~ 2FF _h	1801 _h
PDO2 (receive)	0110	301 _h ~ 37F _h	1401 _h
PDO3 (transmit)	0111	381 _h ~ 3FF _h	1802 _h
PDO3 (receive)	1000	401 _h ~ 47F _h	1402 _h
PDO4 (transmit)	1001	481 _h ~ 4FF _h	1803 _h
PDO4 (receive)	1010	501 _h ~ 57F _h	1403 _h
SDO (transmit)	1011	581 _h ~ 5FF _h	1200 _h
SDO (receive)	1100	601 _h ~ 67F _h	1200 _h
Heartbeat	1110	701 _h ~ 77F _h	1016 _h 、1017 _h

Note:

1. PDO/SDO's send/receive is observed by (slave) CAN.
2. Our drive's CANopen protocol currently supports 4 transmit PDO and 4 receive PDO.

3.2 SDO

SDO is used to visit the object dictionary of a device. Visitor is called client. The CANopen device whose object dictionary is visited and required to supply the asked service is called server. CANopen messages from a client and servo all contain 8 bits (Not all of them are meaningful). A request from a client must be confirmed by a server


There are 2 method of conveying SDO:

- ☐ Expedited transfer: contains 4 bytes at maximum
- ☐ Segmented transfer: contains more than 4 bytes

Basic structure of SDO:

Byte0	Byte1~2	Byte3	Byte4~7
SDO	Object reference	Sub-object reference	data


SDO read/write command structure:



Example:

UINT8 / INT8 Reading of Obj. 6061_00 _h Returning data: 01 _h		Writing of Obj. 1401_02 _h Data: EF _h	
Command:	40 _h 61 _h 60 _h 00 _h	2F _h 01 _h 14 _h 02 _h EF _h	
Answer:	4F _h 61 _h 60 _h 00 _h 01 _h	60 _h 01 _h 14 _h 02 _h	
UINT16 / INT16 Reading of Obj. 6041_00 _h Returning data: 1234 _h		Writing of Obj. 6040_00 _h Data: 03E8 _h	
Command:	40 _h 41 _h 60 _h 00 _h	2B _h 40 _h 60 _h 00 _h E8 _h 03 _h	
Answer:	4B _h 41 _h 60 _h 00 _h 34 _h 12 _h	60 _h 40 _h 60 _h 00 _h	
UINT32 / INT32 Reading of Obj. 6093_01 _h Returning data: 12345678 _h		Writing of Obj. 6093_01 _h Data: 12345678 _h	
Command:	40 _h 93 _h 60 _h 01 _h	23 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h	
Answer:	43 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h	60 _h 93 _h 60 _h 01 _h	

SDO-error messages:



Error code F3 F2 F1 F0	Description
05 03 00 00 _h	Toggle bit not alternated
05 04 00 01 _h	Client / server command specifier not valid or unknown
06 01 00 00 _h	Unsupported access to an object
06 01 00 01 _h	Attempt to read a write only object
06 01 00 02 _h	Attempt to write a read only object
06 02 00 00 _h	Object does not exist in the object dictionary
06 04 00 41 _h	Object cannot be mapped to the PDO
06 04 00 42 _h	The number and length of the objects to be mapped would exceed PDO length
06 04 00 47 _h	General internal incompatibility in the device
06 07 00 10 _h	Data type does not match, length of service parameter does not match
06 07 00 12 _h	Data type does not match, length of service parameter too high
06 07 00 13 _h	Data type does not match, length of service parameter too low
06 09 00 11 _h	Sub-index does not exist
06 04 00 43 _h	General parameter incompatibility
06 06 00 00 _h	Access failed due to an hardware error * ¹⁾
06 09 00 30 _h	Value range of parameter exceeded
06 09 00 31 _h	Value of parameter written too high
06 09 00 32 _h	Value of parameter written too low
06 09 00 36 _h	Maximum value is less than minimum value
08 00 00 20 _h	Data cannot be transferred or stored to the application * ¹⁾
08 00 00 21 _h	Data cannot be transferred or stored to the application because of local control
08 00 00 22 _h	Data cannot be transferred or stored to the application because of the present device state * ³⁾
08 00 00 23 _h	No Object Dictionary is present * ²⁾

3.3 PDO

PDO is applied to transferring real time data which will be conveyed from a producer to one or multiple clients. Data transferring will be limited to 1 to 8 bytes. There is no hand-shake restriction in PDO communication, which means data has been redefined, so clients could process the received data for vary short time. PDO content will be only defined by its CAN ID, assuming producers and clients know PDO content from its CAN ID.

2 objects in object dictionary are used for each PDO.

- PDO communication parameter: It contains COB-ID, transferring type, restriction time and cycle of timer used by PDO.

- PDO mapping parameter: It contains a list of objects in the object dictionary. These objects are mapped into PDO,

includes their data length in bits. Producers and clients must know this mapping to explain the content of PDO.

The content of PDO's message is predefined or configured when the network initializes. Mapping application object into PDO is described in object dictionary. If a device (producer and client) support dynamic mapping, SDO could be used to configure PDO's mapping parameter. Our servo drive supports dynamic PDO mapping. There are 2 rules for PDO mapping to follow..

1. Each PDO could be mapped into 4 objects.
2. The length of each PDO will be no more than 64 bits.

PDO mapping process:

1. Set the sub-index of PDO coordinated mapping parameter (1600_h, 1601_h, 1A00_h or 1A01_h) as 0.
2. Revise the sub-index from 1 to 4 of PDO coordinated mapping parameter (1600_h, 1601_h, 1A00_h or 1A01_h).
3. Set the sub-index 0 of PDO coordinated mapping parameter(1600_h, 1601_h, 1A00_h or 1A01_h) as legal number(number of PDO's mapping objects)
4. PDO mapping completing.

There are multiple ways to transmit PDO:

- Synchronous (Synchronization by receiving SYNC object)

Cycle: Transmit triggered after every 1 to 240 SYNC messages.

- Asynchronous

Transmit triggered by special object event regulated in sub-object protocol.

Transmit type of PDO

Transmit Type	Description	PDO
0	Reserved	—
1~240	SYNC: It represents the number of SYNC objects between 2 PDOs.	TPDO/RPDO
240~253	Reserved	—
254	Asynchronous: If the content of PDO has changed, PDO transmit will be triggered.	TPDO
255	Asynchronous: The content of PDO will be periodically updated and transmitted.	TPDO/RPDO

One PDO could set a frozen time which is the shortest interval time between 2 continuous PDO. It could prevent the bus

from being occupied by amount of data with high priority. Frozen time is defined by 16 bit unsigned integer number and its unit is 100us.

One PDO could set a timing period. When the regulated time is violated, a PDO transmit could be triggered without a trigger bit. Object timing period is defined as 16 bit unsigned integer and its unit is 1ms.

PDO mapping case:

Map the 3 objects to PDO1 (transmit). PDO1 (transmit) is required to be asynchronous periodic type with period time as much as 10ms and frozen time as much as 2ms.

Object	Index — Sub-index	Description
statusword	6041 _h – 00 _h	Status word
modes_of_operation_display	6061 _h – 00 _h	Practical operational mode
Position_Acture_Value	6064 _h – 00 _h	Practical position

1) Clear number_of_mapped_objects

number_of_mapped_objects(1A00_h: 00_h)= 0

2) Set the parameter for mapping objects

Index =6041_h Subin. = 00_h Length = 10_h ⇒ 1st_mapped_object(1A00_h: 01_h)= 60410010_h

Index =6061_h Subin. = 00_h Length = 08_h ⇒ 2st_mapped_object(1A00_h: 02_h)= 60610008_h

Index =60FD_h Subin. = 00_h Length = 20_h ⇒ 3st_mapped_object(1A00_h: 03_h) = 60FD0020_h

3) Set number_of_mapped_objects

number_of_mapped_objects(1A00_h: 00_h)= 3

4) Set PDO communication parameter

PDO1 (transmit) is asynchronous periodical type ⇒ transmission_type (1800_h: 02_h)= FF_h

Frozen time 2ms(20×100us) ⇒ inhibit_time (10A0_h: 03_h)= 14_h

Period time: 10ms(10×1ms) ⇒ event_time (1800_h: 05_h)= 0A_h

5) PDO mapping complete.

PDO parameter

ProNet drive contains 4 transmit PDOs and 4 receive PDOs. The detailed communication parameter and mapping parameter of the first transmit/receive PDO is as below and those of the rest 3 transmit/receive PDO are the same as the first PDO.

Index	1800 _h
Name	transmit_pdo_parameter_tpdo1
Object Code	RECORD
No. of Elements	4

Sub-Index	01 _h
Description	cob_id_used_by_pdo_tpdo1
Data Type	UINT32
Access	RW
PDO Mapping	NO
Units	—
Value Range	181 _h ...1FF _h , Bit 31 may be set
Default Value	181 _h

Sub-Index	02 _h
Description	transmission_type_tpdo1
Data Type	UINT8
Access	RW
PDO Mapping	NO
Units	—
Value Range	1...240,254,255
Default Value	255

Sub-Index	03 _h
Description	inhibit_time_tpdo1
Data Type	UINT16
Access	RW
PDO Mapping	NO
Units	100μs
Value Range	—
Default Value	100

Sub-Index	05 _h
Description	event_time_tpdo1
Data Type	UINT16
Access	RW
PDO Mapping	NO
Units	1ms
Value Range	—
Default Value	10

Index	1A00 _h
Name	transmit_pdo_mapping_tpdo1
Object Code	RECORD
No. of Elements	2

Sub-Index	00 _h
Description	number_of_mapped_objects_tpdo1
Data Type	UINT8
Access	RW
PDO Mapping	NO
Units	—
Value Range	0...4
Default Value	2

Sub-Index	01 _h
Description	first_mapped_object_tpdo1
Data Type	UINT32
Access	RW
PDO Mapping	NO
Units	—
Value Range	—
Default Value	See table

Sub-Index	02 _h
Description	second_mapped_object_tpdo1
Data Type	UINT32
Access	RW
PDO Mapping	NO
Units	—
Value Range	—

Default Value	See table
---------------	-----------

Sub-Index	03 _h
Description	third_mapped_object_tpdo1
Data Type	UINT32
Access	RW
PDO Mapping	NO
Units	—
Value Range	—
Default Value	See table

Sub-Index	04 _h
Description	fourth_mapped_object_tpdo1
Data Type	UINT32
Access	RW
PDO Mapping	NO
Units	—
Value Range	—
Default Value	See table

1、T-PDO1

Index	Comment	Type	Acc.	Default Value
1800 _h _00 _h	number of entries	UINT8	RO	04 _h
1800 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000181 _h
1800 _h _02 _h	transmission type	UINT8	RW	FF _h
1800 _h _03 _h	inhibit time (100 μs)	UINT16	RW	64 _h
1800 _h _05 _h	event time (1ms)	UINT16	RW	0A _h
1A00 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1A00 _h _01 _h	first mapped object	UINT32	RW	60410010 _h
1A00 _h _02 _h	second mapped object	UINT32	RW	60640020 _h
1A00 _h _03 _h	third mapped object	UINT32	RW	00 _h
1A00 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

2、T-PDO2

Index	Comment	Type	Acc.	Default Value
1801 _h _00 _h	number of entries	UINT8	RO	04 _h
1801 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000281 _h
1801 _h _02 _h	transmission type	UINT8	RW	FF _h
1801 _h _03 _h	inhibit time (100 μs)	UINT16	RW	64 _h
1801 _h _05 _h	event time (1ms)	UINT16	RW	0A _h
1A01 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1A01 _h _01 _h	first mapped object	UINT32	RW	60640020 _h
1A01 _h _02 _h	second mapped object	UINT32	RW	60610010 _h
1A01 _h _03 _h	third mapped object	UINT32	RW	00 _h
1A01 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

3、T-PDO3

Index	Comment	Type	Acc.	Default Value
1802 _h _00 _h	number of entries	UINT8	RO	04 _h
1802 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000281 _h
1802 _h _02 _h	transmission type	UINT8	RW	FF _h
1802 _h _03 _h	inhibit time (100 μs)	UINT16	RW	64 _h
1802 _h _05 _h	event time (1ms)	UINT16	RW	0A _h
1A02 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1A02 _h _01 _h	first mapped object	UINT32	RW	60640020 _h
1A02 _h _02 _h	second mapped object	UINT32	RW	60610010 _h
1A02 _h _03 _h	third mapped object	UINT32	RW	00 _h
1A02 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

4、T-PDO4

Index	Comment	Type	Acc.	Default Value
1803 _h _00 _h	number of entries	UINT8	RO	04 _h
1803 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000281 _h
1803 _h _02 _h	transmission type	UINT8	RW	FF _h
1803 _h _03 _h	inhibit time (100 μs)	UINT16	RW	64 _h
1803 _h _05 _h	event time (1ms)	UINT16	RW	0A _h
1A03 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1A03 _h _01 _h	first mapped object	UINT32	RW	60640020 _h
1A03 _h _02 _h	second mapped object	UINT32	RW	60610010 _h
1A03 _h _03 _h	third mapped object	UINT32	RW	00 _h
1A03 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

If transmit tye is 254 (if PDO content has changed,trigger will be sent by PDO),using the following object can shield parts of PDO changers.Only when the un-shield bit has changed, PDO is occur.If wants shielding any bit, the corresponding bit of object write to 0.

tpdo_1_transmit_mask

Index	Comment	Type	Acc.	Default Value
2000 _h _00 _h	number of entries	UINT8	RO	02 _h
2000 _h _01 _h	tpdo_1_transmit_mask_low	UINT32	RW	FFFFFFFF _h
2000 _h _02 _h	tpdo_1_transmit_mask_high	UINT32	RW	FFFFFFFF _h

tpdo_2_transmit_mask

Index	Comment	Type	Acc.	Default Value
2001 _h _00 _h	number of entries	UINT8	RO	02 _h
2001 _h _01 _h	tpdo_2_transmit_mask_low	UINT32	RW	FFFFFFFF _h
2001 _h _02 _h	tpdo_2_transmit_mask_high	UINT32	RW	FFFFFFFF _h

tpdo_3_transmit_mask

Index	Comment	Type	Acc.	Default Value
2002 _h _00 _h	number of entries	UINT8	RO	02 _h
2002 _h _01 _h	tpdo_1_transmit_mask_low	UINT32	RW	FFFFFFFF _h
2002 _h _02 _h	tpdo_1_transmit_mask_high	UINT32	RW	FFFFFFFF _h

tpdo_4_transmit_mask

Index	Comment	Type	Acc.	Default Value
2003 _h _00 _h	number of entries	UINT8	RO	02 _h
2003 _h _01 _h	tpdo_2_transmit_mask_low	UINT32	RW	FFFFFFFF _h
2003 _h _02 _h	tpdo_2_transmit_mask_high	UINT32	RW	FFFFFFFF _h

1、R-PDO1

Index	Comment	Type	Acc.	Default Value
1400 _h _00 _h	number of entries	UINT8	RO	02 _h
1400 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000201 _h
1400 _h _02 _h	transmission type	UINT8	RW	FF _h
1600 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1600 _h _01 _h	first mapped object	UINT32	RW	60400010 _h
1600 _h _02 _h	second mapped object	UINT32	RW	60FF0020 _h
1600 _h _03 _h	third mapped object	UINT32	RW	00 _h
1600 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

2、R-PDO2

Index	Comment	Type	Acc.	Default Value
1401 _h _00 _h	number of entries	UINT8	RO	02 _h
1401 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000301 _h
1401 _h _02 _h	transmission type	UINT8	RW	FF _h
1601 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1601 _h _01 _h	first mapped object	UINT32	RW	60FF0020 _h
1601 _h _02 _h	second mapped object	UINT32	RW	60600010 _h
1601 _h _03 _h	third mapped object	UINT32	RW	00 _h
1601 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

3、R-PDO3

Index	Comment	Type	Acc.	Default Value
1402 _h _00 _h	number of entries	UINT8	RO	02 _h
1402 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000301 _h
1402 _h _02 _h	transmission type	UINT8	RW	FF _h
1602 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1602 _h _01 _h	first mapped object	UINT32	RW	60FF0020 _h
1602 _h _02 _h	second mapped object	UINT32	RW	60600010 _h
1602 _h _03 _h	third mapped object	UINT32	RW	00 _h
1602 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

4、R-PDO4

Index	Comment	Type	Acc.	Default Value
1403 _h _00 _h	number of entries	UINT8	RO	02 _h
1403 _h _01 _h	COB-ID used by PDO	UINT32	RW	00000301 _h
1403 _h _02 _h	transmission type	UINT8	RW	FF _h
1603 _h _00 _h	number of mapped objects	UINT8	RW	02 _h
1603 _h _01 _h	first mapped object	UINT32	RW	60FF0020 _h
1603 _h _02 _h	second mapped object	UINT32	RW	60600010 _h
1603 _h _03 _h	third mapped object	UINT32	RW	00 _h
1603 _h _04 _h	fourth mapped object	UINT32	RW	00 _h

3.4 SYNC message

Synchronization object is used for controlling data synchronize transmit. For example: starting synchronously several axes. The transmission of synchronous message is based on Producer-Customer model. All the nodes of synchronous PDO can receive (at the same time) the message as customer and synchronize other node.

General mode:

CANopen suggests a COB-ID with highest priority to ensure that synchronized signal could be transmitted properly. Without transferring data, SYNC message could be as short as possible.


The identifier the servo controller receives SYNC messages are fixed to 080h. The identifier can be read via the object **cob_id_sync**.

Index	1005 _h
Name	cob_id_sync
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	NO
Units	—
Value Range	80000080 _h , 00000080 _h
Default Value	00000080 _h

3.5 Emergency message

When an alarm occurs to drive, CANopen will initiate an Emergency message to inform the current drive type and error code to clients. Error code displayed on panel can be read on low byte of 603Fh object.

The structure of Emergency message:



Alarm code

error_code (hex)	Description
2310	Over current
3100	Instantaneous power failure
3110	Over voltage
3120	Under voltage
5080	RAM exception
5210	AD sampling error
5420	Regenerative resistor error
5421	Regenerative resistor exception
5581	Parameter checksum exception
5582	electric gear error
5583	Motor type or drive type error
6100	Illegal error code
6120	PDO mapping error
6300	CAN communication error(Address or communication baud rate error)
7303	serial encoder error
7305	Incremental encoder error
7380	Resolver error
8100	CAN communication exception
8110	CAN bus overflow
8120	PASSIVE CAN bus turn to PASSIVE
8130	Heartbeat error
8140	CAN BUS OFF
8200	Length of CAN messages error
8210	Length of receiving PDO error
8311	Overload alarm
8480	Over speed alarm
8681	Forward run prohibited POT
8682	Reverse run prohibited NOT

Relevant parameter:

Index	1003 _h
Name	pre_defined_error_field
Object Code	ARRAY
No. of Elements	4
Data Type	UINT32

Sub-Index	01 _h
Description	standard_error_field_0
Access	RO
PDO Mapping	NO
Units	—
Value Range	—
Default Value	—


Sub-Index	02 _h
Description	standard_error_field_1
Access	RO
PDO Mapping	NO
Units	—
Value Range	—
Default Value	—

Sub-Index	03 _h
Description	standard_error_field_2
Access	RO
PDO Mapping	NO
Units	—
Value Range	—
Default Value	—

Sub-Index	04 _h
Description	standard_error_field_3
Access	RO
PDO Mapping	NO
Units	—
Value Range	—
Default Value	—

3.6 HEARTBEAT message

Structure of the heartbeat message:




Relevant parameter:


Index	1017 _h
Name	producer_heartbeat_time
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	NO
Units	ms
Value Range	0 - 65535
Default Value	0

3.7 Network management (NMT service)

Structure of the message:



NMT-State machine:




CS	Meaning	Transition	Target state
01 _h	Start Remote Node	3, 6	Operational
02 _h	Stop Remote Node	5, 8	Stopped
80 _h	Enter Pre-Operational	4, 7	Pre-Operational
81 _h	Reset Application	12, 13, 14	Reset Application
82 _h	Reset Communication	9, 10, 11	Reset Communication

Name	Meaning	SDO	PDO	NMT
Reset Application	No communication. All CAN objects are set to their reset values (application parameter set).	-	-	-
Reset Communication	No communication. The CAN controller will be re-initialised.	-	-	-
Initialising	State after Hardware Reset. Reset of the CAN node, sending of the Bootup message	-	-	-
Pre-Operational	Communication via SDOs possible. PDOs inactive (No sending / receiving)	X	-	X
Operational	Communication via SDOs possible. PDOs active (sending / receiving)	X	X	X
Stopped	No communication except heartbeat + NMT	-	-	X

Chapter 4 Conversion factors(factor group)

Servo controllers will be used in a huge number of applications: As direct drive, with gear or for linear drives. To allow an easy parameterization for all kinds of applications, the servo controller can be parameterized in such a way that all values like the demand velocity refer to the driven side of the plant. The necessary calculation is done by the servo controller.



The default setting of the Factor Group is as follows:

Value	Name	Unit	Remark
Length	position units	Increments	Increments per revolution *
Velocity	speed units	1R /10min	0.1rpm
Acceleration	Acceleration units	1R/10min/s	0.1rpm/s
Jerk	jerk units	pulse/(s*100μs*100μs)	Range:1-20,more smaller,more smooth

* : Common incremental encoder: 10000P/R

Resolver: 65536P/R

17 bit incremental encoder: 131072P/R

17 bit absolute encoder: 131072P/R

4.1 Related parameters

Index	Object	Name	Type	Attr.
6093 _h	ARRAY	position factor	UINT32	RW
6094 _h	ARRAY	velocity factor	UINT32	RW
6097 _h	ARRAY	acceleration factor	UINT32	RW


4.2 Position factor

The object **position factor** converts all values of length of the application from **Position units** into the internal unit **increments** (*encoder resolution* equals 1 Revolution). It consists of numerator and divisor:

Index	6093 _h
Name	position factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	numerator
Access	RW
PDO Mapping	YES
Units	—
Value Range	—
Default Value	When power on, this value will be initiated to parameter Pn201

Sub-Index	02 _h
Description	division
Access	RW
PDO Mapping	YES
Units	—
Value Range	—
Default Value	When power on, this value will be initiated to parameter Pn202



To calculate the **position factor** the following values are necessary:

gear_ratio Ratio between revolutions on the driving side (R_{IN}) and revolutions on the driven side (R_{OUT}).

feed_constant Ratio between revolutions on the driven side (R_{OUT}) and equivalent motion in **position_units** (e.g. 1 rev = 360°)

The calculation of the **position_factor** is done with the following equation:

$$\text{position factor} = \frac{\text{numerator}}{\text{division}} = \frac{\text{gear_ratio} * \text{encoder_resolution}}{\text{feed_constant}}$$

Note:

Encoder type	Encoder_resolution(Unit: Inc)
Common incremental encoder	10000
Resolver	65535
17 bit incremental encoder	131072
17 bit absolute encoder: 131072P/R	131072

4.3 Velocity factor

The object **velocity factor** converts all speed values of the application from **speed_units** into the internal unit **revolutions 0.1rpm**. It consists of numerator and divisor

Index	6094 _h
Name	velocity factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	numerator
Access	RW
PDO Mapping	YES
Units	—
Value Range	—
Default Value	1

Sub-Index	02 _h
Description	division
Access	RW
PDO Mapping	YES
Units	—
Value Range	—
Default Value	1

In principle the calculation of the **velocity factor** is composed of two parts: A conversion factor from internal units of length into **position_units** and a conversion factor from internal time units into user defined time units (e.g. from seconds to minutes). The first part equals the calculation of the **position_factor**. For the second part another factor is necessary for the calculation:

time_factor_v Ratio between internal and user defined time units.
 (z.B. **1 min = 1/10 10 min**)

gear_ratio Ratio between revolutions on the driving side (RIN) and revolutions on the driven side (ROUT).

feed_constant Ratio between revolutions on the driven side (ROUT) and equivalent motion in position_units (e.g. 1 R = 360°)

The calculation of the **velocity factor** is done with the following equation:

$$\text{velocity factor} = \frac{\text{numerator}}{\text{division}} = \frac{\text{gear_ratio} * \text{time_factor_v}}{\text{feed_constant}}$$

4.4 Acceleration factor

The object **acceleration_factor** converts all acceleration values of the application from **acceleration_units** into the internal unit (0.1rpm). It consists of numerator and divisor:

Index	6094 _h
Name	acceleration factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Description	numerator
Access	RW
PDO Mapping	YES
Units	—
Value Range	—
Default Value	1

Sub-Index	02 _h
Description	division
Access	RW
PDO Mapping	YES
Units	—
Value Range	—
Default Value	1

The calculation of the **acceleration_factor** is also composed of two parts: A conversion factor from internal units of length into **position_units** and a conversion factor from internal time units squared into user defined time units squared (e.g. from seconds² to minutes²). The first part equals the calculation of the **position_factor**. For the second part another factor is necessary for the calculation

time_factor_a Ratio between internal time units squared and user defined time units squared
 (z.B.: $1\text{min}^2 = 1\text{min} * \text{min} = 60\text{s} * 1\text{min} = 60/10 \text{ 10min/s}$)

gear_ratio Ratio between revolutions on the driving side (RIN) and revolutions on the driven side (ROUT).

feed_constant Ratio between revolutions on the driven side (ROUT) and equivalent motion in position_units (e.g. $1\text{ R} = 360^\circ$)

The calculation of the **acceleration_factor** is done with the following equation:

$$\text{acceleration factor} = \frac{\text{numerator}}{\text{division}} = \frac{\text{gear_ratio} * \text{time_factor_a}}{\text{feed_constant}}$$


Chapter 5 Position control function

This chapter describes all parameters which are required for the position controller. The desired position value (**position_demand_value**) of the trajectory generator is the input of the position controller. Besides this the actual position value (**position_actual_value**) is supplied by the angle encoder (resolver, incremental encoder, etc.). The behaviour of the position controller can be influenced by parameters.

It is possible to limit the output quantity (**control_effort**) in order to keep the position control system stable. The output quantity is supplied to the speed controller as desired speed value. In the **Factor Group** all input and output quantities are converted from the application-specific units to the respective internal units of the controller


The following subfunctions are defined in this chapter:

1. Trailing error (Following Error)



Trailing error (Following Error) – Function Survey

The deviation of the actual position value (**position_actual_value**) from the desired position value (**position_demand_value**) is named trailing error. If for a certain period of time this trailing error is bigger than specified in the trailing error window (**following_error_window**) bit 13 (**following_error**) of the object **statusword** will be set to 1.




Trailing error (following error)

The permissible time can be defined via the object **following_error_time_out**. Figure above shows how the window function is defined for the message "following error". The range between $x_i - x_0$ and $x_i + x_0$ is defined symmetrically

around the desired position (**position_demand_value**) x_i . For example the positions x_{t2} and x_{t3} are outside this window (**following_error_window**). If the drive leaves this window and does not return to the window within the time defined in the object **following_error_time_out** then bit 13 (**following_error**) in the **statusword** will be set to 1.


2. Position Reached

This function offers the chance to define a position window around the target position (**target_position**). If the actual position of the drive is within this range for a certain period of time – the **position_window_time** – bit 10 (**target_reached**) will be set to 1 in the statusword.



Position reached-function description

Figure below shows how the window function is defined for the message "position reached". The position range between $x_i - x_0$ and $x_i + x_0$ is defined symmetrically around the target position (**target_position**) x_i . For example the positions x_{t0} and x_{t1} are inside this position window (**position_window**). If the drive is within this window a timer is started. If this timer reaches the time defined in the object **position_window_time** and the drive uninterruptedly was within the valid range between $x_i - x_0$ and $x_i + x_0$, bit 10 (**target_reached**) will be set in the **statusword**. As far as the drive leaves the permissible range, bit 10 is cleared and the timer is set to zero.



Position reached

Parameters:

Index	Object	Name	Type	Attr.
6062 _h	VAR	position_demand_value	INT32	RO
6063 _h	VAR	position_actual_value*	INT32	RO
6064 _h	VAR	position_actual_value	INT32	RO
6065 _h	VAR	following_error_window	UINT32	RW
6066 _h	VAR	following_error_time_out	UINT16	RW
6067 _h	VAR	position_window	UINT32	RW
6068 _h	VAR	position_time	UINT16	RW
60FA _h	VAR	control_effort	INT32	RO

Index	6062 _h
Name	position_demand_value
Object Code	VAR
Data Type	INT32
Access	RO
PDO Mapping	YES
Units	position units
Value Range	--
Default Value	--

Index	6064 _h
Name	position_ actual _value
Object Code	VAR
Data Type	INT32
Access	RO
PDO Mapping	YES
Units	position units
Value Range	--
Default Value	--

Index	6065 _h
Name	following_error_window
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	position units
Value Range	0 – 7FFFFFFF _h
Default Value	256

Index	6066 _h
Name	following_error_time_out
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES
Units	Ms
Value Range	0 – 65535
Default Value	0

Index	60FA _h
Name	control_effort
Object Code	VAR
Data Type	INT32
Access	RO
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	--

Index	6067 _h
Name	position_window
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	position units
Value Range	--
Default Value	400

Index	6068 _h
Name	position_time
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES
Units	Ms
Value Range	0 – 65535
Default Value	0

Chapter 6 Device control

The following chapter describes how to control the servo controller using CANopen, i.e. how to switch on the power stage or to reset an error.

6.1 State diagram (State machine)

Using CANopen the complete control of the servo is done by two objects. Via the **controlword** the host is able to control the servo, as the status of the servo can be read out of the **statusword**. The following items will be used in this chapter:


State: The servo controller is in different states dependent on for instance if the power stage is alive or if an error has occurred. States defined under CANopen will be explained in this chapter.

Example: **SWITCH_ON_DISABLED**

State Transition: Just as the states it is defined as well how to move from one state to another (e.g. to reset an error). These state transitions will be either executed by the host by setting bits in the **controlword** or by the servo controller itself, if an error occurs for instance.

Command: To initiate a state transition defined bit combinations have to be set in the **controlword**. Such bit combination are called command. Example: **Enable Operation**

State diagram: All the states and all state transitions together form the so called state diagram: A survey of all states and the possible transitions between two states..



State diagram of the servo controller

The state diagram can be divided into three main parts: "Power Disabled" means the power stage is switched off and "Power Enabled" the power stage is active. The area "Fault" contains all states necessary to handle errors of the controller. The most important states have been highlighted in the Figure: After switching on the servo controller initializes itself and reaches the state **SWITCH_ON_DISABLED** after all. In this state CAN communication is possible and the servo controller can be parameterized (e.g. the mode of operation can be set to "velocity control"). The power stage remains switched off and the motor shaft is freely rotatable. Through the state transitions 2, 3 and 4 – principally like the controller enable under CANopen - the state **OPERATION_ENABLE** will be reached. In this state the power stage is live and the servo controller controls the motor according to the parameterized mode of operation. Therefore previously ensure that the servo controller has been parameterized correctly and the according demand value is zero. The state transition 9 complies with disabling the power stage, i.e. the motor is freely rotatable.

Status	Description
Not Ready to Switch On	The servo controller executes its self-test. The CAN communication is not working
Switch On Disabled	The self-test has been completed. The CAN communication is activated..
Ready to Switch On	Servo driver is waiting for the state of Switch and servo motor is not at power stage
Switched On	The power stage is alive.
Operation Enable	The motor is under voltage and is controlled according to operational mode
Quick Stop Active	Servo driver will be stopped through its fixed way,
Fault Reaction Active	Servo driver tests error and will be stopped through its fixed way, with motor's power stage alive
Fault	An error has occurred. The power stage has been switched off.

6.2 Relevant parameters of device control

Index	Object	Name	Type	Attr.
6040 _h	VAR	controlword	UINT16	RW
6041 _h	VAR	statusword	UINT16	RO
605A _h	VAR	quick_stop_option_code	INT16	RW
605B _h	VAR	shutdown_option_code	INT16	RW
605C _h	VAR	disabled_operation_option_code	INT16	RW
605D _h	VAR	halt_option_code	INT16	RW
605E _h	VAR	fault_reaction_option_code	INT16	RW

6.2.1 Controlword

Index	6040 _h
Name	controlword
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES


Units	--
Value Range	--
Default Value	0

Controlword bit description is as below...

15	11	10	9	8	7	6	4	3	2	1	0
manufacturer specific	reserved	halt	Fault reset	Operation mode specific	Enable operation	Quick stop	Enable voltage	Switch on			

Bit0 ~ 3 and Bit7:

Transmit of status machine is triggered by 5 bits coordinated control code as below...

Command	Bit of the <i>controlword</i>					Transitions
	Fault reset	Enable operation	Quick stop	Enable voltage	Switch on	
Shutdown	0	X	1	1	0	2,6,8
Switch on	0	0	1	1	1	3*
Switch on	0	1	1	1	1	3**
Disable voltage	0	X	X	0	X	7,9,10,12
Quick stop	0	X	0	1	X	7,10,11
Disable operation	0	0	1	1	1	5
Enable operation	0	1	1	1	1	4,16
Fault reset		X	X	X	X	15

Device control list

Note: X means this bit could be ignored.

Bit4、5、6、8:

The definition of this 4 bit is different in different control mode...

Bit	Control Mode		
	profile position mode	profile velocity mode	homing mode
4	new_set_point	reserved	start_homeing_operation
5	change_set_immediatly	reserved	reserved
6	abs/rel	reserved	reserved
8	Halt	Halt	Halt

Other bits: all reserved

6.2.2 Statusword

Index	6041 _h
Name	statusword
Object Code	VAR
Data Type	UINT16
Access	RO
PDO Mapping	YES

Units	--
Value Range	--
Default Value	--

Explanation of statusword bit is as below:

bit	name
0	Ready to switch on
1	Switched on
2	Operation enabled
3	Fault
4	Voltage enabled
5	Quick stop
6	Switch on disabled
7	Warning
9~8	Not used now
10	Target reached
11	Internal limit active
13~12	Operation mode specific
15~14	Not used now

Bit0 ~ 3 , Bit5 and Bit6:

The combination of this bit indicates the status of drives.

Value (binary)	State
xxxx xxxx x0xx 0000	Not ready to switch on
xxxx xxxx x1xx 0000	Switch on disabled
xxxx xxxx x01x 0001	Ready to switch on
xxxx xxxx x01x 0011	Switched on
xxxx xxxx x01x 0111	Operation enabled
xxxx xxxx x00x 0111	Quick stop active
xxxx xxxx x0xx 1111	Fault reaction active
xxxx xxxx x0xx 1000	Fault

Bit4: Voltage enabled

Main power is on when this bit is 1.

Bit5: Quick stop

Driver will follow setting (605A_h: quick_stop_option_code) to halt when this bit is 0.

Bit7: Warning

Driver detects alarm when this bit is 1.

Bit10: Target reached

In different control modes the meaning of this bit is different.

In profile position mode, when set position is reached, this bit is set. When Halt is booted, speed is reduced to 0 and this bit will be set. When new position is set, this bit will be cleared.

In profile Velocity Mode, when the speed reaches the targeted speed, this bit will be set. When Halt is booted and speed is reduced to 0, this bit is set.

Bit11: Internal limit active

When this bit is 1, it indicates that internal torque has surpassed the set value, or reached the max.forward/reverse run. It can be confirmed by reading object 60FDh (digital inputs) .

Bit12, 13:

These 2 bits mean different in different control mode...

Bit	Control mode		
	profile position mode	profile velocity mode	homing mode
12	Set-point acknowledge	Speed	Homing attained
13	Following error	Max slippage error	Homing error

Other bits:

All reserved.

6.2.3 Shutdown_option_code

The object **shutdown_option_code** determines the behaviour if the state transition 8 (from **OPERATION ENABLE** to **READY TO SWITCH ON**) will be executed.

Index	605B _h
Name	shutdown_option_code
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	NO
Units	--
Value Range	0,1
Default Value	0

Value	Name
0	Power stage will be switched off. Motor is freely rotatable.
1	Switch off the power stage after the motor stops deceleration.

6.2.4 Disable_operation_option_code

The object **disable_operation_option_code** determines the behaviour if the state transition 5 (from **OPERATION ENABLE** to **SWITCHED ON**) will be executed.

Index	605C _h
Name	disable_operation_option_code
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	NO
Units	--
Value Range	0,1
Default Value	0

Value	Description
0	Power stage will be switched off. Motor is freely rotatable.。
1	Switch off the power stage after the motor stops deceleration.

6.2.5 Quick_stop_option_code

The object **quick_stop_option_code** determines the behaviour if a **Quick Stop** will be executed.

Index	605A _h
Name	quick_stop_option_code
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	NO
Units	--
Value Range	0,1,2,5,6
Default Value	0

value	Description
0	Power stage will be switched off. Motor is freely rotatable.
1	Switch off the power stage after the motor stops deceleration.
2	Power stage will be shut down after the motor decelerates to still urgently.
5	QuickStop is alive after the motor decelerates to still.
6	QuickStop is alive after the motor decelerates urgently to still.

6.2.6 Halt_option_code

Halt_option_code determines how to stop when bit.8 (halt) of controlword is set to 1.

Index	605D _h
Name	halt_option_code
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	NO
Units	--
Value Range	1,2
Default Value	0

Value	Description
1	The motor decelerates to still.
2	The motor decelerates urgently to still

6.2.7 Fault_reaction_option_code

When an error is occurred, fault_reation_option_code determines how to stop.

Index	605D _h
Name	fault_reaction_option_code
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	NO
Units	--
Value Range	0
Default Value	0

Value	Description
0	Power stage will be switched off. Motor is freely rotatable.

Chapter 7 Control mode

PRONET drive currently supports 3 control modes in CANopen DSP402:

HOMING MODE

PROFILE VELOCITY MODE

PROFILE POSITION MODE

This chapter mainly describes three control modes as above.

7.1 Relevant parameter of control mode

Index	Object	Name	Type	Attr.
6060 _h	VAR	modes_of_operation	INT8	RW
6061 _h	VAR	modes_of_operation_display	INT8	RO

7.1.1 Modes_of_operation

Drive control mode will be determined by parameters in modes_of_operation.

Index	6060 _h
Name	modes_of_operation
Object Code	VAR
Data Type	INT8
Access	RW
PDO Mapping	YES
Units	--
Value Range	1,3,6
Default Value	0

Value	Description
0	NOP MODE
1	PROFILE POSITION MODE
3	PROFILE VELOCITY MODE
6	HOMING MODE

7.1.2 Modes_of_operation_display

Drive current control mode could be read from parameters in modes_of_operation_display.

Index	6061 _h
Name	modes_of_operation_display
Object Code	VAR
Data Type	INT8
Access	RO
PDO Mapping	YES
Units	--
Value Range	1,3,6
Default Value	0

Note: The current control mode could be only known from parameters in modes_of_operation_display

7.2 Homing mode

PRONET servo drive currently supports multiple homing mode and users could choose the suitable homing mode. For example, if an incremental encoder is applied in servomotor, then homing mode of Zero impulse could be chosen and if serial encoder or resolver is applied in servomotor then Zero impulse homing mode couldn't be selected.

The user can determine the velocity, acceleration, and the kind of homing operation. After the servo controller has found its reference the zero position can be moved to the desired point via the object home_offset (607C_h).

7.2.1 Control word of homing mode

15 ~ 9	8	7 ~ 5	4	3 ~ 0
*	Halt	*	home_start_operation	*

*: referred to previous chapters ...

Name	Value	Description
Homing operation start	0	Homing mode inactive
	0 → 1	Start homing mode
	1	Homing mode active
	1 → 0	Interrupt homing mode
Halt	0	Execute the instruction of bit 4
	1	Stop axle with homing acceleration

7.2.2 Status word of homing mode

15 ~ 14	13	12	11	10	9 ~ 0
---------	----	----	----	----	-------

*	homing_error	homing_attained	*	target_reached	*
---	--------------	-----------------	---	----------------	---

*: referred to previous chapters


Name	Value	Description
Target reached	0	Halt = 0: Home position not reached Halt = 1: Axle decelerates
	1	Halt = 0: Home position reached Halt = 1: Axle has velocity 0
Homing attained	0	Homing mode not yet completed
	1	Homing mode carried out successfully
Homing error	0	No homing error
	1	Homing error occurred; Homing mode carried out not successfully; The error cause is found by reading the error code

7.2.3 Relevant parameter of homing mode

Index	Object	Name	Type	Attr.
607C _h	VAR	home_offset	INT32	RW
6098 _h	VAR	homing_method	INT8	RW
6099 _h	ARRAY	homing_speeds	UINT32	RW
609A _h	VAR	homing_acceleration	INT32	RW

home_offset

The object **home_offset** determines the displacement of the zero position to the limit resp. reference switch position.



Index	607C _h
Name	home_offset
Object Code	VAR
Data Type	INT32
Access	RW
PDO Mapping	YES
Units	position units
Value Range	--
Default Value	0

homing_method

The negative and positive limit switch, the reference switch and the (periodic) zero impulse of the angle encoder.

Index	6098 _h
Name	homing_method
Object Code	VAR
Data Type	INT8
Access	RW
PDO Mapping	YES
Units	--
Value Range	1,2,3,4,17,18,19,20
Default Value	1

Homing method value description

Value	Direction	Target	Reference point for Home position	DS402
1	Negative	NOT	Zero impulse	1
2	Positive	POT	Zero impulse	2
3	Negative	Reference switch	Zero impulse	3
4	Positive	Reference switch	Zero impulse	4
17	Negative	NOT	NOT	17
18	Positive	POT	POT	18
19	Negative	Reference switch	Reference switch	19
20	Positive	Reference switch	Reference switch	20

homing_speeds

There are two kinds of speeds required to find reference point, speed during search for switch and speed during search for zero.

Index	6099 _h
Name	homing_speeds
Object Code	ARRAY
No. of Elements	2
Data Type	INT32

Sub-Index	01 _h
Name	speed_during_search_for_switch
Object Code	VAR
Data Type	INT32
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	0

Sub-Index	02 _h
Name	speed_during_search_for_zero
Object Code	VAR

Data Type	INT32
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	0

homing_acceleration


The objects **homing_acceleration** determine the acceleration which is used for all acceleration and deceleration operations during the search for reference.

Index	609A _h
Name	homing_acceleration
Object Code	VAR
Data Type	INT32
Access	RW
PDO Mapping	YES
Units	acceleration units
Value Range	--
Default Value	0

7.2.4 Homing sequences


Method 1: Negative limit switch using zero impulse evaluation

If this method is used the drive first moves relatively quick into the negative direction until it reaches the negative limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the first zero impulse of the angle encoder in positive direction from the limit switch.。




Method 2: Positive limit switch using zero impulse evaluation

If this method is used the drive first moves relatively quick into the positive direction until it reaches the positive limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the first zero impulse of the angle encoder in negative direction from the limit switch.




Methods 3 and 4: Reference switch and zero impulse evaluation

These two methods use the reference switch which is only active over parts of the distance. These reference methods are particularly useful for round-axis applications where the reference switch is activated once per revolution. In case of method 3 the drive first moves into positive and in case of method 4 into negative direction. Depending on the direction of the motion the zero position refers to the first zero impulse in negative or positive direction from the reference switch. This can be seen in the two following diagrams.




Method 17~20: Homing operation to the negative limit switch

If this method is used the drive first moves relatively quick into the negative direction until it reaches the negative limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the descending edge from the negative limit switch.



Method 35: set current position as the homing point.



Notes: When starting homing on homing method about input signal, the rotation direction of servo motor is associated with the initial status of the input signal. Changing the initial status by inverse input on set Pn516/Pn517 if it is necessary. When using reference switch homing, I/O should be set as C:HmRef by Pn509/Pn510. Setting parameters refer to <ProNet series AC servo user's manual>.

7.3 Profile velocity mode

7.3.1 Control word of profile velocity mode

15 ~ 9	8	7 ~ 4	3 ~ 0
*	Halt	*	*

*: referred to previous chapters

Name	Value	Description
Halt	0	Execute the motion
	1	Stop axle

7.3.2 Status word of velocity mode

15 ~ 14	13	12	11	10	9 ~ 0
*	MaxSlippageError	Speed	*	Target reached	*

*: Referred to previous chapters

Name	Value	Description
Target reached	0	Halt = 0: <i>Target velocity</i> not (yet) reached Halt = 1: Axle decelerates
	1	Halt = 0: <i>Target velocity</i> reached Halt = 1: Axle has velocity 0
Speed	0	Speed is not equal 0
	1	Speed is equal 0
Max slippage error	0	Maximum slippage not reached
	1	Maximum slippage reached

7.3.3 Relevant parameters of profile velocity mode

Index	Object	Name	Type	Attr.
6069 _h	VAR	velocity_sensor_actual_value	INT32	RO
606B _h	VAR	velocity_demand_value	INT32	RO
606C _h	VAR	velocity_actual_value	INT32	RO
609D _h	VAR	velocity_window	UINT16	RW
606E _h	VAR	velocity_window_time	UINT16	RW
606F _h	VAR	velocity_threshold	UINT16	RW
6070 _h	VAR	velocity_threshold_time	UINT16	RW
60FF _h	VAR	target_velocity	INT32	RW

velocity_sensor_actual_value

The speed encoder is read via the object **velocity_sensor_actual_value**. The value is normalised in internal units. The velocity demand value can be read via this object.

Index	6069 _h
Name	velocity_sensor_actual_value
Object Code	VAR
Data Type	INT32
Access	RW
PDO Mapping	YES
Units	0.1rmps (1R/10min)
Value Range	--
Default Value	--

velocity_demand_value

The velocity demand value can be read via this object. The unit of this object is the unit of user's speed unit. The velocity demand value can be read via this object.

Index	606B _h
Name	velocity_demand_value
Object Code	VAR
Data Type	INT32
Access	RO
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	--

velocity_actual_value

The actual velocity value can be read via the object **velocity_actual_value**. The velocity demand value can be read via this object.

Index	606C _h
Name	velocity_actual_value
Object Code	VAR
Data Type	INT32
Access	RO
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	--

velocity_window

With the object **velocity_window** a tolerance window for the velocity actual value will be defined for comparing the **velocity_actual_value** (606C_h) with the target velocity (**target_velocity** object 60FF_h). If the difference is smaller than the velocity window (606D_h) for a longer time than specified by the object **velocity_window_time** (606E_h) bit 10 (**target_reached**) will be set in the object **statusword**.

Index	606D _h
Name	velocity_window
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	20 R/10min

velocity_window_time

The object **velocity_window_time** serves besides the object 606D_h: **velocity_window** to adjust the window comparator.

Index	606E _h
Name	velocity_window_time
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES
Units	ms
Value Range	--
Default Value	0

velocity_threshold

The object **velocity_threshold** determines the velocity underneath the axis is regarded as stationary. As soon as the **velocity_actual_value** exceeds the **velocity_threshold** longer than the **velocity_threshold_time** bit 12 is cleared in the **statusword**.

Index	606F _h
Name	velocity_threshold
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	10 R/10min

velocity_threshold_time

The object **velocity_threshold** determines the velocity below the axis is regarded as stationary. Its unit is ms. As soon as the **velocity_actual_value** exceeds the **velocity_threshold** longer than the **velocity_threshold_time** bit 12 is cleared in the **statusword**.

Index	6070 _h
Name	velocity_threshold_time
Object Code	VAR
Data Type	UINT16
Access	RW
PDO Mapping	YES
Units	ms
Value Range	--
Default Value	0

target_velocity

The object **target_velocity** is the setpoint for the ramp generator.

Index	60FF _h
Name	target_velocity
Object Code	VAR
Data Type	INT32
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	0

7.4 Profile position mode

7.4.1 Control word of profile position mode

15 ~ 9	8	7	6	5	4	3 ~ 0
*	Halt	*	abs / rel	Change set immediately	New set-point	*

*: referred to previous chapter

Name	Value	Description
New set-point	0	Does not assume <i>target position</i>
	1	Assume <i>target position</i>
Change set immediately	0	Finish the actual positioning and then start the next positioning
	1	Interrupt the actual positioning and start the next positioning
abs / rel	0	<i>Target position</i> is an absolute value
	1	<i>Target position</i> is a relative value
Halt	0	Execute positioning
	1	Stop axle with <i>profile deceleration</i> (if not supported with <i>profile acceleration</i>)

7.4.2 Status word of profile position mode

15 ~ 14	13	12	11	10	9 ~ 0
*	Following error	Set_point acknowledge	*	Target reached	*

*: referred to previous chapter

Name	Value	Description
Target reached	0	Halt = 0: <i>Target position</i> not reached Halt = 1: Axle decelerates
	1	Halt = 0: <i>Target position</i> reached Halt = 1: Velocity of axle is 0
Set-point acknowledge	0	Trajectory generator has not assumed the positioning values (yet)
	1	Trajectory generator has assumed the positioning values
Following error	0	No following error
	1	Following error

7.4.3 Revelant parameters of profile position mode

Index	Object	Name	Type	Attr.
607A _h	VAR	target_position	INT32	RW
6081 _h	VAR	profile_velocity	UINT32	RW
6082 _h	VAR	end_velocity	UINT32	RW
6083 _h	VAR	profile_acceleration	UINT32	RW
6084 _h	VAR	profile_deceleration	UINT32	RW
6085 _h	VAR	quick_stop_deceleration	UINT32	RW
6086 _h	VAR	motion_profile_type	INT16	RW
60A4-01 _h	VAR	Profile_jerk1	UINT32	RW

target_position

The object **target_position** determines the destination the servo controller moves to. The target position (**target_position**) is interpreted either as an absolute or relative position. This depends on bit 6 (**relative**) of the object **control word**.

Index	607A _h
Name	target_position
Object Code	VAR
Data Type	INT32
Access	RW
PDO Mapping	YES
Units	position units
Value Range	--
Default Value	0

profile_velocity

The object **profile_velocity** specifies the speed that usually is reached during a positioning motion at the end of the acceleration ramp. The object **profile_velocity** is specified in **speed_units**.

Index	6081 _h
Name	profile_velocity
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	0

end_velocity

The object **end_velocity** defines the speed at the target position (**target_position**). Usually this object has to be set to zero so that the controller stops when it reaches the target position. For gapless sequences of positionings a value unequal zero can be set.

Index	6082 _h
Name	end_velocity
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	speed units
Value Range	--
Default Value	0

profile_acceleration

The object **profile_acceleration** determines the maximum acceleration used during a positioning motion. It is specified in user specific acceleration units (**acceleration_units**).

Index	6083 _h
Name	profile_acceleration
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	acceleration units
Value Range	--
Default Value	100000 R/10min/s

profile_deceleration

The object **profile_deceleration** specifies the maximum deceleration used during a positioning motion. This object is specified in the same units as the object **profile_acceleration**

Index	6084 _h
Name	profile_deceleration
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	acceleration units
Value Range	--
Default Value	100000 R/10min/s

quick_stop_deceleration

The object **quick_stop_deceleration** determines the deceleration if a Quick Stop will be executed.

Index	6085 h
Name	quick_stop_deceleration
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	acceleration units
Value Range	--
Default Value	200000 R/10min/s

motion_profile_type

The object **motion_profile_type** is used to select the kind of speed profile. At present only a linear trpezia profile(set as 0) and a stable S linear jerk profile are available(set as 2).

Index	6086 h
Name	motion_profile_type
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	YES
Units	--
Value Range	0
Default Value	0

profile_jerk1

profile_jerk1 is used to set the jerk of speed profile. The value is more smaller,the speed changing is more smooth.

Index	60A4 -01h
Name	profile_jerk1
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Units	jerk units
Value Range	1-20
Default Value	5pulse/(s*100μs*100μs)

7.4.4 Function Description

When the speed profile is trapezia(motion_profile_type=0),two different ways to apply target positions to the servo controller are supported.

Single setpoints

After reaching the **target_position** the servo controller signals this status to the host by the bit **target_reached** (Bit 10 of **controlword**) and then receives a new setpoint. The servo controller stops at the **target_position** before starting a move to the next setpoint.

Set of setpoints


After reaching the **target_position** the servo controller immediately processes the next **target_position** which results in a move where the velocity of the drive normally is not reduced to zero after reaching a setpoint.

These Two methods are controlled by the bit4 and **bit5** in the object **controlword** and **set_point_acknowledge** in the object **statusword**. These bits are in a request-response relationship. So it is possible to prepare one positioning job while another job is still running.

Simple job positioning:

At first set NMT as Operational and control mode parameter (6061h) as 1.

1. At first the positioning data (**target_position**: 607A_h, **profile_velocity**, **end_velocity** and **profile_acceleration**) are transferred to the servo controller.
2. The host can start the positioning motion by setting the bit4 (**new_set_point**) in the **controlword** as 1, bit5 (**change_set_immediately**) as 0 and bit6 as absolute or referential type according to target position type (absolute or referential).
3. This will be acknowledged by the servo controller by setting the bit **set_point_acknowledge** in the **statusword** when the positioning data has been copied into the internal buffer. Motion could be started now.
4. When the target is reached, drive will be acknowledged by bit 10 (**target_reached**) in status word. And then it will run gapless according to program or accept a new target position.



Gapless sequence of positioning job:

At first set NMT as Operational and control mode parameter (6061h) as 1.

1. At first the positioning data (**target_position**: 607A_h, **profile_velocity**, **end_velocity** and **profile_acceleration**) are transferred to the servo controller.
2. The host can start the positioning motion by setting the bit4 (**new_set_point**) in the **controlword** as 1, bit5 (**change_set_immediately**) as 0 and bit6 as absolute or referential type according to target position type (absolute or


referential).

3. This will be acknowledged by the servo controller by setting the bit **set_point_acknowledge** in the **statusword** when the positioning data has been copied into the internal buffer. Motion could be started now.


4. Second positioning data (**target_position**: 607Ah, **profile_velocity**, **end_velocity** and **profile_acceleration**) are transferred to the servo controller.

5. The host can start the positioning motion by setting the bit4 (**new_set_point**) in the **controlword** as 1, bit5 (**change_set_immediately**) as 0 and bit6 as absolute or referential type according to target position type (absolute or referential).

6. When the 1 target is reached driver will move forward to second target position. When the second target position is reached drive will be acknowledged by bit10 (target reached) in status word. And then it will be executed by program or accept another new target position.



When the speed profile is S (motion_profile_type=2), only single setpoints is available. 6083 h (profile_acceleration) limits max. acceleration. 6081h(profile_velocity) limits max.speed. 60A4-01 h (VAR Profile_jerk1) limits the jerk.now only symmetrical S linear is available.



7.5 Interpolation position mode

7.5.1 Control word of interpolation position mode

15 ~ 9	8	7	6	5	4	3 ~ 0
*	Halt	*	*	*	Enable ip mode	*

*: Please refer to the chapters ahead

Name	Value	Description
Enable ip mode	0	Interpolated position mode inactive
	1	Interpolated position mode active
Halt	0	Execute the instruction of bit 4
	1	Stop axle

7.5.2 Status word of interpolation position mode

15 ~ 14	13	12	11	10	9 ~ 0
*	*	ip mode active	*	Target reached	*

*: Please refer to the chapters ahead

Name	Value	Description
Target reached	0	Halt = 0: Position not (yet) reached Halt = 1: Axle decelerates
	1	Halt = 0: Position reached Halt = 1: Axle has velocity 0
ip mode active	0	Interpolated position mode inactive
	1	Interpolated position mode active

7.5.3 Parameters of position interpolation control

Index	Object	Name	Type	Attr.
60C0 _h	VAR	Interpolation sub mode select	INT16	RW
60C1 _h	ARRAY	Interpolation data record	INT32	RW
60C2 _h	RECORD	Interpolation time period		RW

Interpolation sub mode select

Interpolation sub mode select is used to select the method of interpolation under IP control. Pronet servo drive only offers linear interpolation.

Index	60C0h
Name	Interpolation sub mode select
Object Code	VAR
Data Type	INT16
Access	RW
PDO Mapping	NO
Value Range	0
Default Value	0
Comment	0: Linear interpolation

Interpolation data record

Interpolation data record is used to reserve interpolation data. Our servo drive's interpolation command only uses the first data whose subindex is 1.

Index	60C1h
Subindex	0
Object Code	ARRAY
Data Type	INT32
Access	RO
PDO Mapping	YES
Value Range	INT8
Default Value	2
Comment	number of entries

Index	60C1h
Subindex	1
Object Code	ARRAY
Data Type	INT32
Access	RW
PDO Mapping	YES
Value Range	INT32
Default Value	0
Comment	the first parameter of ip function

Index	60C1h
Subindex	2
Object Code	ARRAY
Data Type	INT32
Access	RW
PDO Mapping	YES
Value Range	INT32
Default Value	0
Comment	The second parameter of ip function

Interpolation time period

Interpolation time period is used to reserve the time data of interpolation position.

Index	60C2h
Object Code	RECORD
Data Type	Interpolation time period record (0080h)
Category	Conditional: mandatory if ip, csp, csv or cst mode is supported

Index	60C2h
Subindex	0
Object Code	RECORD
Data Type	UINT8
Access	C
PDO Mapping	NO
Value Range	02
Default Value	02
Comment	Highest sub-index supported

Index	60C2h
Subindex	01
Object Code	RECORD
Data Type	UINT8
Access	RW
PDO Mapping	YES
Value Range	UINT8
Default Value	01
Comment	Interpolation time period value

Index	60C2h
Subindex	02
Object Code	RECORD
Data Type	INT8
Access	RW
PDO Mapping	YES
Value Range	-128 to +63
Default Value	-3
Comment	Interpolation time index

7.5.4 Function description

Some hints:

1. In our servo drive, there is no buffer for position data so in IP control, all the position data needs to be updated by the controller. To achieve synchronization, controllers need to send the updated position at first and then use SYNC signal to make all the servo drive receive the synchronization information. After receiving the synchronization information, servo drive will synchronize its internal clock. Please notice that the sync period should be not bigger than interpolation cycle period in order to keep the updating of interpolation data.
2. In IP mode, the host should at first set the servo's PDO receiving method into sync mode (Use SYNC frame to receive and send synchronization information). Because SYNC is broad casted, every servo drive will only update PDO data after receiving this signal.
3. Before SYNC is sent, we need host to send position data Xi and control word to the servo drive.
4. When there is data delay, servo drive will use the last sync date to do interpolation.
5. After one sync period, if there is no further data updating, interpolation cycle overtime alarm (A 69) will happen. And then servo drive will stop.

Recommended RPDO configuration:

When you use only one RPDO,

Control word(index:6040h,subindex:0h)	32bit position reference (index:60C1h,subindex:01h)
---------------------------------------	--

When you use two RPDO,

Control word(index:6040h,subindex:0h)
32bit position reference (index:60C1h,subindex:01h)

Configuration process:

1. Configure PDO. (RPDO1 is configured as index: 6040h, subindex: 0h, RPDO2 is configured as index 60c1h, subindex: 1h)
2. Set interpolation cycle time 2105h and 60C2, the unit is micro send (us). Please notice that both values need to be configured. For example, if the cycle time is 2ms, you need to set 2105h as 2000 and 60c2:01 as 2, 60c2:02 as -3.
3. Set sync cycle time (1006h), the unit is micro send (us)
4. Set PDO as Sync mode (Set the object dictionary (index: 1400h, subindex: 02h) as 1. Set object dictionary (index: 1401h, subindex: 02h) as 1). If sending PDO needs to be in sync mode as well, we need to set object dictionary (index: 1800h, subindex: 02h) as 1 and (index: 6060h, subindex: 0h) as 1 as well.
5. NMT starts node.

Chapter 8 Parameters of the CAN interface

Parameter	Name and discription	Reboot required	Available for which control method	Functions and content
Pn006	Hexadecimal	required	ALL	Pn006.0 Bus type selection [0]No bus [1]PROFIBUS-DP V0/V1 [2]PROFIBUS-DP V2 [3] CANopen Pn006.1 Reserved Pn006.2 Low-frequency vibration suppression switch [0]Low-frequency vibration suppression function disabled [1]Low-frequency vibration suppression function enabled Pn006.3 Reference input filter for open collector signal [0] when pulse is difference input, servo receiving pulse frequency $\leq 4M$ [1] when pulse is difference input, servo receiving pulse frequency $\leq 650K$ [2] when pulse is difference input, servo receiving pulse frequency $\leq 150K$
Pn703	Hexadecimal	required	ALL	Pn703.0 CANopen baud rate [0] 50Kbps [1] 100Kbps [2] 125Kbps [3] 250Kbps [4] 500Kbps [5] 1Mbps Pn703.1 Reserved Pn703.2 Reserved Pn703.3 Reserved
Pn704	Axis address	required	ALL	CANopen axis address

Chapter 9 CAN communication example

The entire test below is based on two conditions ...

1. Communication has been established correctly.
2. The address of the servo drive is 1.

9.1 SDO configuration

SDO operation is to read and write parameters (06001→ host sends 0581-→slave sends)

Address: 0x3022 (Pn034) . Write 1000. And then read this parameter.

Activate the downloading process: 2B, 3022, 00, FC18

That is ...

601 2B 22 30 00 18 FC 00 00

The servo drive should respond 60, 3022, 00, 00, 00, 00, 00

That is 581 60 22 30 00 00 00 00

Activate the uploading: 40, 3022, 00, 0000

That is 601 40 22 30 00 00 00 00

The servo drive needs to respond: 43, 3022, 00, FC18

That is: 581 43 22 30 00 18 FC 00 00

9.2 PDO Configuration

// pulse, Speed 0.1rpm

Example: To configure two RPDO, one of which is 6040h and the other are 607A and 6081h)

RPDO MAPPING

601 2F 00 16 00 00 00 00 //RPDO1 stop

first RPDO 201

601 23 00 16 01 10 00 40 60 //6040h

601 2F 00 16 00 01 00 00 00 // RPDO1 enable

601 2F 01 16 00 00 00 00 00 //RPDO2 stop

Second RPDO 301

601 23 01 16 01 20 00 7A 60 //607Ah and 6081h

601 23 01 16 02 20 00 81 60

601 2F 01 16 00 02 00 00 00// RPDO2 enable

And then set the transmit PDO as SYNC or Timing method. The default setting is Time method.

After configuring the PDO, if you need to activate the configuration, you need to reset the communication.

NMT is OPERATIONAL: 00 01 01// (the first "01" is the start node instruction, the second "01" is the number of the node)

Attention:

1. Before configuration, please stop PDO. For example, Cleaning the value with index 1600h and sub-index 00, cleaning the value to 0 is necessary). After configuration, please set a correct number of PDO (For example, set the value with index 1600h and sub-index 00 as 1) to activate the PDO.
2. Please pay attention to the data length and number. Wrong setting will lead to wrong configuration.

9.3 Profile Position Mode

At first, please configure PDO according to the example above and activate the communication.

And then, please set the control mode.

601 2F 60 60 00 01 00 00 00//set 6060h as 1 (position contrl is PP)

And then, set status machine

601 2B 40 60 00 06 00 00 00//set 6040h as 6

601 2B 40 60 00 07 00 00 00 //set 6040h as 7

601 2B 40 60 00 0F 00 00 00 //set 6040h as F, servo-on;

And then, send data by PDO

Let servo motor rotate for 5 revolutions (Set PDO1 as 6040(status word), PDO2 as 607A(position pulse number) and 6081(velocity, unit as much as 0.1rpm)

Send RPDO2 The data is as below ...

301 50 C3 00 00 2C 01 00 00(50000,300)// 50 C3 00 00 is position data, that is, 50000 pulses; 2C 01 00 00 is speed, that is, 30rpm;

Send RPDO1 as below

- 1、201 0F 00 //; Clear the bit4 of 6040 as 0.
- 2、201 1F 00 // Clear the bit4 of 6040 as 1 and servo motor is operating under absolute position; Motor runs.
- 3、201 0F 00 //Clear the bit4 of 6040.
- 4、201 5F 00 // Clear the bit4 of 6040 as 1. The servo motor runs under incremental position.
- 5、201 0F 00 //Clear bit4 of 6040 as 0.

Attention:

- 1) The servo drive is using ↑of 6040's bit 4 to accept new position order. So after every single operation, the bit needs to be cleared. Host needs to check bit12 of status word 6040 in the servo drive to decide whether or not to give new data to servo systems. When status word 6041 in the servo drives 0, it means the servo drive is ready for new data and order. If the value is 1, the order won't be executed even if there is data for the servo drive to receive.
- 2) In absolute approach, continuous position updating is required.

If you want to change the operating distance, you need to send RPDO2 again.

RPDO2:

301 B0 3C FF FF 2C 01 00 00 (-50000,-300)//That is, -50000 pulses; 30rpm.

9.4 Interplate Position Mode

At first, configure PDO

/receive 2 PDO by default: RPDO1: 6040 RPDO2: 60C1,sub01

// Send two PDO by default: TPDO1: 6041 TPDO2: 6064/606C

// pulse, Velocity 0.1rpm

Configure 2 RPDO, RPDO1: 6040h RPDO2: 60C1h, sub01

RPDO MAPPING

601 2F 00 16 00 00 00 00 00 //RPDO1 stop

first RPDO 201

601 23 00 16 01 10 00 40 60 //6040h

601 2F 00 16 00 01 00 00 00 // RPDO1 enable

601 2F 01 16 00 00 00 00 00 //RPDO2 stop

Second RPDO 301

601 23 01 16 01 20 01 C1 60 //60C1h,sub01

601 2F 01 16 00 01 00 00 00// RPDO2 enable

Configure 2 TPDO, TPDO1: 6041h TPDO2: 6064h/606Ch

RPDO MAPPING

601 2F 00 1A 00 00 00 00 00 //TPDO1 stop

first RPDO 181

601 23 00 1A 01 10 00 41 60 //6041h

601 2F 00 1A 00 01 00 00 00 // TPDO1 enable

601 2F 01 1A 00 00 00 00 00 //RPDO2 stop

Second RPDO 281

601 23 01 1A 01 20 00 64 60 //6064h and 606Ch

601 23 01 1A 02 20 00 6C 60 //

601 2F 01 1A 00 02 00 00 00// TPDO2 enable

Set Sync time.

601 23 06 10 00 E8 03 00 00 //1006h----->1000us

Set interpolate time

601 2F C2 60 01 10 00 00 00 //60C2h----->1ms

601 2F C2 60 02 FD 00 00 00 //

Configure the PDO receiving and sending both by the means of the sync step and sync frame.

Set 1400h

601 2F 00 14 02 01 00 00 00 //1400----□SYNC

Set 1401h

601 2F 01 14 02 01 00 00 00 //1401----□SYNC

Set 1800h

601 2F 00 18 02 01 00 00 00 //1800----□SYNC

Set 1801h

601 2F 01 18 02 01 00 00 00 //1801----□SYNC

Reset the communication to active dynamic PDO configuration.

00 82 01 //reset communication

Set control mode

601 2F 60 60 00 07 00 00 00// (IP position control)

And then, set the status machine

601 2B 40 60 00 06 00 00 00//Set 6040h as 6

601 2B 40 60 00 07 00 00 00 //Set 6040h as 7

601 2B 40 60 00 0F 00 00 00 // Set 6040h as F to servo on.

Activate the communicaiton

00 01 01

The host sends signals by the period of 1000us.

301 10 00 00 00 //16 pulses

201 1F 00 //IP

80 periodical sending

9.5 Homing

Set the control mode as homing control.

601 2F 60 60 00 06 00 00 00// Set the control mode as homing control.

601 2F 98 60 00 04 00 00 00//Use the fourth way to set the homing mode.

Set the status machine

601 2B 40 60 00 06 00 00 00

601 2B 40 60 00 07 00 00 00

601 2B 40 60 00 0F 00 00 00 //Servo On

Send data through PDO. (Set PDO1 as 6040(status word). Set PDO2 as 607A(Position pulse number) and 6081.
(Speed, unit 0.1rpm)

Set the homing method as 10rpm.

601 23 99 60 02 64 00 00 00

Homing is started.

201 1F 00

Cancel homing.

201 0F 00

Chapter 10 Other function

10.1 Bus input

In some case, the switch (homing and limit switch) is committed by upper computer not servo drive.the signal is committed by object 60FE-01h(Physical outputs).

31	30	29	28	27	26	25	24	23...0
CN1_42	CN1_41	CN1_40	CN1_39	CN1_17	CN1_16	CN1_15	CN1_14	reserved

8 high- bit of the object corresponding input signal terminal connector(CN1). The function of the terminals is formed by Pn509/510 or inversing Pn516/517. Enabled bus commit by Pn512/Pn513 for the bus commit bits. Refer to <ProNet Series AC Servo User's Manual>.

Index	60FE _h
Name	Digital outputs
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01 _h
Name	Physical outputs
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Default Value	0

Sub-Index	02 _h
Name	Bit mask
Object Code	VAR
Data Type	UINT32
Access	RW
PDO Mapping	YES
Default Value	0

The host can read the object 60FDh(Digital Inputs) to monitor the switching inputs of the servo.

31-26	2	1	0
reserved	home switch	positive limit switch	negative limit switch

10.2 Dummy object

To a better performance and save bandwidth of the bus ,the host can post data to the different slaves by the same PDO. COB-ID of slave's RPDO should be set as the same value,and dummy object should be mapped to slave's RPDO. Sometimes need to turn off some needless TPDO.

Example of mapping the first RPDO of two nodes:

Node1

```
0x1600-1 = 60C1 00 10H    // Interpolated position
0x1600-2 = 0007 00 10H    // Dummy object 32 bit
0x1600-0 = 2H
```

Node 2

```
0x1600-1 = 0007 00 10H    // Dummy object 32 bit
0x1600-2 = 60C1 00 10H    // Interpolated position
0x1600-0 = 2H
```

Host controller can use one PDO, and map the two slaves'interpolated position to the first and the second objects at the same time.

Example of programming COB-ID: revise COB-ID of Node 2 the first RPDO from 0x202 to 0x201

```
0x1400-1 = 80000201H      //Restrict PDO, and write new COB-ID
0x1400-1 = 00000201H      // Enabled PDO
```

Example of closing TPDO: restrict the second TPDO of Node 2 from transmitting (default COB-ID is 0x282)

```
0x1801-1 = 80000282H
```

Appendix Object dictionary

Index	Subindex	Object	Name	Type	Attr.	PDO	Support				Unit
							All	PP	PV	HM	
2	--	VAR	od_integer8	INT8	RW	YES	•				
3	--	VAR	od_integer16	INT16	RW	YES	•				
4	--	VAR	od_integer32	INT32	RW	YES	•				
5	--	VAR	od_unsigned8	UINT8	RW	YES	•				
6	--	VAR	od_unsigned16	UINT16	RW	YES	•				
7	--	VAR	od_unsigned32	UINT32	RW	YES	•				
1000	--	VAR	device_type	UINT32	RO	NO	•				
1001	--	VAR	error_register	UINT8	RO	NO	•				
1003	--	VAR	pre_defined_error_field	UINT8	RW	NO	•				
1005	--	VAR	cob_id_sync	UINT32	RW	NO	•				
1006	--	VAR	communication_cycle_period	UINT32	RW	NO	•				
1007	--	VAR	synchronous_window_length	UINT32	RW	NO	•				
1014	--	VAR	cob_id_emergency_message	UINT32	RW	NO	•				
1016	--	ARRAY	consumer_heartbeat_time	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		consumer_heartbeat_time1	UINT32	RW	NO	•				
1017		VAR	producer_heartbeat_time	UINT16	RW	NO	•				
1018	--	RECORD	identity_object	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		vendor_id	UINT32	RO	NO	•				
	2		product_code	UINT32	RO	NO	•				
	3		revision_number	UINT32	RO	NO	•				
	4		serial_number	UINT32	RO	NO	•				
1029	--	ARRAY	error_behaviour	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		communication_error	UINT8	RW	NO	•				
1200	--	RECORD	server_sdo_parameter	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		cob_id_client_server	UINT32	RO	NO	•				
	2		cob_id_server_client	UINT32	RO	NO	•				
1400	--	RECORD	receive_pdo_parameter_rpdo1	--	--	--	•				
	0		number_of_entries_rpdo1	UINT8	RO	NO	•				
	1		cob_id_used_by_pdo_rpdo1	UINT32	RO	NO	•				
	2		transmission_type_rpdo1	UINT8	RW	NO	•				
1401	--	RECORD	receive_pdo_parameter_rpdo2	--	--	--	•				
	0		number_of_entries_rpdo2	UINT8	RO	NO	•				

Index	Subindex	Object	Name	Type	Attr.	PDO	Support				Unit
							All	PP	PV	HM	
	1		cob_id_used_by_pdo_rpdo2	UINT32	RO	NO	•				
	2		transmission_type_rpdo2	UINT8	RW	NO	•				
1402	--	RECORD	receive_pdo_parameter_rpdo3	--	--	--	•				
	0		number_of_entries_rpdo3	UINT8	RO	NO	•				
	1		cob_id_used_by_pdo_rpdo3	UINT32	RO	NO	•				
	2		transmission_type_rpdo3	UINT8	RW	NO	•				
1403	--	RECORD	receive_pdo_parameter_rpdo4	--	--	--	•				
	0		number_of_entries_rpdo4	UINT8	RO	NO	•				
	1		cob_id_used_by_pdo_rpdo4	UINT32	RO	NO	•				
	2		transmission_type_rpdo4	UINT8	RW	NO	•				
1600	--	RECORD	receive_pdo_mapping_rpdo1	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_rpdo1	UINT32	RW	NO	•				
	2		second_mapped_object_rpdo1	UINT32	RW	NO	•				
	3		third_mapped_object_rpdo1	UINT32	RW	NO	•				
	4		fourth_mapped_object_rpdo1	UINT32	RW	NO	•				
1601	--	RECORD	receive_pdo_mapping_rpdo2	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_rpdo2	UINT32	RW	NO	•				
	2		second_mapped_object_rpdo2	UINT32	RW	NO	•				
	3		third_mapped_object_rpdo2	UINT32	RW	NO	•				
	4		fourth_mapped_object_rpdo2	UINT32	RW	NO	•				
1602	--	RECORD	receive_pdo_mapping_rpdo3	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_rpdo3	UINT32	RW	NO	•				
	2		second_mapped_object_rpdo3	UINT32	RW	NO	•				
	3		third_mapped_object_rpdo3	UINT32	RW	NO	•				
	4		fourth_mapped_object_rpdo3	UINT32	RW	NO	•				
1603	--	RECORD	receive_pdo_mapping_rpdo4	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_rpdo4	UINT32	RW	NO	•				
	2		second_mapped_object_rpdo4	UINT32	RW	NO	•				
	3		third_mapped_object_rpdo4	UINT32	RW	NO	•				
	4		fourth_mapped_object_rpdo4	UINT32	RW	NO	•				
1800	--	RECORD	transmit_pdo_parameter_tpdo1	--	--	--	•				
	0		number_of_entries_tpdo1	UINT32	RO	NO	•				
	1		cob_id_used_by_pdo_tpdo1	UINT32	RO	NO	•				
	2		transmission_type_tpdo1	UINT8	RW	NO	•				
	3		inhibit_time_tpdo1	UINT16	RW	NO	•				
	5		event_timer_tpdo1	UINT16	RW	NO	•				

Index	Subindex	Object	Name	Type	Attr.	PDO	Support				Unit
							All	PP	PV	HM	
1801	--	RECORD	transmit_pdo_parameter_tpdo2	--	--	--	•				
	0		number_of_entries_tpdo2	UINT32	RO	NO	•				
	1		cob_id_used_by_pdo_tpdo2	UINT32	RO	NO	•				
	2		transmission_type_tpdo2	UINT8	RW	NO	•				
	3		inhibit_time_tpdo2	UINT16	RW	NO	•				
	5		event_timer_tpdo2	UINT16	RW	NO	•				
1802	--	RECORD	transmit_pdo_parameter_tpdo3	--	--	--	•				
	0		number_of_entries_tpdo3	UINT32	RO	NO	•				
	1		cob_id_used_by_pdo_tpdo3	UINT32	RO	NO	•				
	2		transmission_type_tpdo3	UINT8	RW	NO	•				
	3		inhibit_time_tpdo3	UINT16	RW	NO	•				
	5		event_timer_tpdo3	UINT16	RW	NO	•				
1803	--	RECORD	transmit_pdo_parameter_tpdo4	--	--	--	•				
	0		number_of_entries_tpdo4	UINT32	RO	NO	•				
	1		cob_id_used_by_pdo_tpdo4	UINT32	RO	NO	•				
	2		transmission_type_tpdo4	UINT8	RW	NO	•				
	3		inhibit_time_tpdo4	UINT16	RW	NO	•				
	5		event_timer_tpdo4	UINT16	RW	NO	•				
1A00	--	RECORD	transmit_pdo_mapping_tpdo1	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_tpdo1	UINT32	RW	NO	•				
	2		second_mapped_object_tpdo1	UINT32	RW	NO	•				
	3		third_mapped_object_tpdo1	UINT32	RW	NO	•				
	4		fourth_mapped_object_tpdo1	UINT32	RW	NO	•				
1A01	--	RECORD	transmit_pdo_mapping_tpdo2	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_tpdo2	UINT32	RW	NO	•				
	2		second_mapped_object_tpdo2	UINT32	RW	NO	•				
	3		third_mapped_object_tpdo2	UINT32	RW	NO	•				
	4		fourth_mapped_object_tpdo2	UINT32	RW	NO	•				
1A02	--	RECORD	transmit_pdo_mapping_tpdo3	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_tpdo3	UINT32	RW	NO	•				
	2		second_mapped_object_tpdo3	UINT32	RW	NO	•				
	3		third_mapped_object_tpdo3	UINT32	RW	NO	•				
	4		fourth_mapped_object_tpdo3	UINT32	RW	NO	•				
1A03	--	RECORD	transmit_pdo_mapping_tpdo4	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		first_mapped_object_tpdo4	UINT32	RW	NO	•				

Index	Subindex	Object	Name	Type	Attr.	PDO	Support				Unit
							All	PP	PV	HM	
	2		second_mapped_object_tpdo4	UINT32	RW	NO	•				
	3		third_mapped_object_tpdo4	UINT32	RW	NO	•				
	4		fourth_mapped_object_tpdo4	UINT32	RW	NO	•				
2000	--	RECORD	mask_tpdo1	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		mask1_tpdo1	UINT32	RW	NO	•				
	2		mask2_tpdo1	UINT32	RW	NO	•				
2001	--	RECORD	mask_tpdo2	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		mask1_tpdo2	UINT32	RW	NO	•				
	2		mask2_tpdo2	UINT32	RW	NO	•				
2002	--	RECORD	mask_tpdo3	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		mask1_tpdo3	UINT32	RW	NO	•				
	2		mask2_tpdo3	UINT32	RW	NO	•				
2003	--	RECORD	mask_tpdo4	--	--	--	•				
	0		number_of_entries	UINT8	RO	NO	•				
	1		mask1_tpdo4	UINT32	RW	NO	•				
	2		mask2_tpdo4	UINT32	RW	NO	•				
2105	0	VAR	sync_time_period	UINT32	RW	NO	•				

Index	Subindex	Object	Name	Type	Attr.	PDO	Support					Unit
							All	IP	PP	PV	HM	
3000	--	VAR	Pn000	UINT16	RW	NO	•					--
3001	--	VAR	Pn001	UINT16	RW	NO	•					--
3002	--	VAR	Pn002	UINT16	RW	NO	•					--
3003	--	VAR	Pn003	UINT16	RW	NO	•					--
3004	--	VAR	Pn004	UINT16	RW	NO	•					--
3005	--	VAR	Pn005	UINT16	RW	NO	•					--
3006	--	VAR	Pn006	UINT16	RW	NO	•					--
3007	--	VAR	Pn007	UINT16	RW	NO	•					--
3010	--	VAR	Pn100	UINT16	RW	NO	•					--
3011	--	VAR	Pn101	UINT16	RW	NO	•					--
3012	--	VAR	Pn102	UINT16	RW	NO	•					Hz
3013	--	VAR	Pn103	UINT16	RW	NO	•					0.1ms
3014	--	VAR	Pn104	UINT16	RW	NO	•					1/s
3015	--	VAR	Pn105	UINT16	RW	NO	•					0.1ms
3016	--	VAR	Pn106	UINT16	RW	NO	•					--
3017	--	VAR	Pn107	UINT16	RW	NO	•					Hz
3018	--	VAR	Pn108	UINT16	RW	NO	•					0.1ms
3019	--	VAR	Pn109	UINT16	RW	NO	•					Hz
301A	--	VAR	Pn110	UINT16	RW	NO	•					0.1ms
301B	--	VAR	Pn111	UINT16	RW	NO	•					r/min
301C	--	VAR	Pn112	UINT16	RW	NO	•					%
301D	--	VAR	Pn113	UINT16	RW	NO	•					0.1ms
301E	--	VAR	Pn114	UINT16	RW	NO	•					%
301F	--	VAR	Pn115	UINT16	RW	NO	•					0.1ms
3020	--	VAR	Pn116	UINT16	RW	NO	•					--
3021	--	VAR	Pn117	UINT16	RW	NO	•					%
3022	--	VAR	Pn118	UINT16	RW	NO	•					--
3023	--	VAR	Pn119	UINT16	RW	NO	•					--
3024	--	VAR	Pn120	UINT16	RW	NO	•					--
3025	--	VAR	Pn121	UINT16	RW	NO	•					--
3026	--	VAR	Pn122	UINT16	RW	NO	•					0.1ms
3027	--	VAR	Pn123	UINT16	RW	NO	•					--
3028	--	VAR	Pn124	UINT16	RW	NO	•					--
3029	--	VAR	Pn125	UINT16	RW	NO	•					0.1ms
302A	--	VAR	Pn126	UINT16	RW	NO	•					--
302B	--	VAR	Pn127	UINT16	RW	NO	•					0.1ms
302C	--	VAR	Pn128	UINT16	RW	NO	•					0.1%
302D	--	VAR	Pn129	UINT16	RW	NO	•					r/min
302E	--	VAR	Pn130	UINT16	RW	NO	•					0.1%

Index	Subindex	Object	Name	Type	Attr.	PDO	Support					Unit
							All	IP	PP	PV	HM	
302F	--	VAR	Pn131	UINT16	RW	NO	●					r/min
3030	--	VAR	Pn132	UINT16	RW	NO	●					0.1%/1000rpm
3055	--	VAR	Pn305	UINT16	RW	NO	●					rpm
3056	--	VAR	Pn306	UINT16	RW	NO	●					ms
3057	--	VAR	Pn307	UINT16	RW	NO	●					ms
3058	--	VAR	Pn308	UINT16	RW	NO	●					ms
3059	--	VAR	Pn309	UINT16	RW	NO	●					ms
305A	--	VAR	Pn310	UINT16	RW	NO	●					--
305B	--	VAR	Pn311	UINT16	RW	NO	●					--
3068	--	VAR	Pn401	UINT16	RW	NO	●					%
3069	--	VAR	Pn402	UINT16	RW	NO	●					%
306A	--	VAR	Pn403	UINT16	RW	NO	●					%
306B	--	VAR	Pn404	UINT16	RW	NO	●					%
306C	--	VAR	Pn405	UINT16	RW	NO	●					%
306D	--	VAR	Pn406	UINT16	RW	NO	●					rpm
306E	--	VAR	Pn407	UINT16	RW	NO	●					HZ
306F	--	VAR	Pn408	UINT16	RW	NO	●					--
3070	--	VAR	Pn409	UINT16	RW	NO	●					HZ
3071	--	VAR	Pn410	UINT16	RW	NO	●					--
3072	--	VAR	Pn411	UINT16	RW	NO	●					0.1 HZ
3073	--	VAR	Pn412	UINT16	RW	NO	●					--
3074	--	VAR	Pn413	UINT16	RW	NO	●					0.1ms
3075	--	VAR	Pn414	UINT16	RW	NO	●					rpm
3078	--	VAR	Pn500	UINT16	RW	NO	●					pulse
3079	--	VAR	Pn501	UINT16	RW	NO	●					rpm
307A	--	VAR	Pn502	UINT16	RW	NO	●					rpm
307B	--	VAR	Pn503	UINT16	RW	NO	●					rpm
307C	--	VAR	Pn504	UINT16	RW	NO	●					256pulse
307D	--	VAR	Pn505	INT16	RW	NO	●					ms
307E	--	VAR	Pn506	UINT16	RW	NO	●					10ms
307F	--	VAR	Pn507	UINT16	RW	NO	●					rpm
3080	--	VAR	Pn508	UINT16	RW	NO	●					10ms
3081	--	VAR	Pn509	UINT16	RW	NO	●					--
3082	--	VAR	Pn510	UINT16	RW	NO	●					--
3083	--	VAR	Pn511	UINT16	RW	NO	●					--
3084	--	VAR	Pn512	UINT16	RW	NO	●					--
3085	--	VAR	Pn513	UINT16	RW	NO	●					--
3086	--	VAR	Pn514	UINT16	RW	NO	●					0.2ms
3088	--	VAR	Pn516	UINT16	RW	NO	●					--
3089	--	VAR	Pn517	UINT16	RW	NO	●					--

Index	Subindex	Object	Name	Type	Attr.	PDO	Support					Unit
							All	IP	PP	PV	HM	
3091	--	VAR	Pn525	UINT16	RW	NO	●					%
30FC	--	VAR	Pn700	UINT16	RW	NO	●					--
30FD	--	VAR	Pn701	UINT16	RW	NO	●					--
30FF	--	VAR	Pn703	UINT16	RW	NO	●					--
3100	--	VAR	Pn704	UINT16	RW	NO	●					--
3200	--	VAR	Fn000-0	UINT16	RO	NO	●					--
3201	--	VAR	Fn000-1	UINT16	RO	NO	●					--
3202	--	VAR	Fn000-2	UINT16	RO	NO	●					--
3203	--	VAR	Fn000-3	UINT16	RO	NO	●					--
3204	--	VAR	Fn000-4	UINT16	RO	NO	●					--
3205	--	VAR	Fn000-5	UINT16	RO	NO	●					--
3206	--	VAR	Fn000-6	UINT16	RO	NO	●					--
3207	--	VAR	Fn000-7	UINT16	RO	NO	●					--
3208	--	VAR	Fn000-8	UINT16	RO	NO	●					--
3209	--	VAR	Fn000-9	UINT16	RO	NO	●					--
320A	--	VAR	Un000	UINT16	RO	NO	●					r/min
320B	--	VAR	Un001	UINT16	RO	NO	●					r/min
320C	--	VAR	Un002	UINT16	RO	NO	●					%
320D	--	VAR	Un003	UINT16	RO	NO	●					%
320E	--	VAR	Un004	UINT16	RO	NO	●					pulse
320F	--	VAR	Un005	UINT16	RO	NO	●					--
3210	--	VAR	Un006	UINT16	RO	NO	●					--
3211	--	VAR	Un007	UINT16	RO	NO	●					--
3212	--	VAR	Un008	UINT16	RO	NO	●					1kHz
3213	--	VAR	Un009	UINT16	RO	NO	●					pulse
3214	--	VAR	Un010	UINT16	RO	NO	●					--
3215	--	VAR	Un011	UINT16	RO	NO	●					--
3216	--	VAR	Un012	UINT16	RO	NO	●					--
3217	--	VAR	Un013	UINT16	RO	NO	●					--
3218	--	VAR	Un014	UINT16	RO	NO	●					--
321E	--	VAR	DSP-Edition	UINT16	RO	NO	●					--
3300	--	VAR	rotates	UINT16	RO	NO	●					--
3301	--	VAR	singlePos	UINT16	RO	NO	●					--

Index	Subindex	Object	Name	Type	Attr.	PDO	Support					Unit
							All	IP	PP	PV	HM	
603F	--	VAR	error_code	UINT16	RO	YES	•					--
6040	--	VAR	controlword	UINT16	RW	YES	•					--
6041	--	VAR	statusword	UINT16	RO	YES	•					--
605A	--	VAR	quick_stop_option_code	INT16	RW	NO	•					--
605B	--	VAR	shutdown_option_code	INT16	RW	NO	•					--
605C	--	VAR	disable_operation_option_code	INT16	RW	NO	•					--
605D	--	VAR	stop_option_code	INT16	RW	NO	•					--
605E	--	VAR	fault_reaction_option_code	INT16	RW	NO	•					--
6060	--	VAR	modes_of_operation	INT8	RW	YES	•					--
6061	--	VAR	modes_of_operation_display	INT8	RO	YES	•					--
6062	--	VAR	position_demand_value	INT32	RO	YES			•			position units
6063	--	VAR	position_actual_value*	INT32	RO	YES			•			inc
6064	--	VAR	position_actual_value	INT32	RO	YES		•	•			position units
6065	--	VAR	following_error_window	UINT32	RW	YES			•			position units
6066	--	VAR	following_error_time_out	UINT16	RW	YES			•			ms
6067	--	VAR	position_window	UINT32	RW	YES			•			position units
6068	--	VAR	position_window_time	UINT16	RW	YES			•			ms
6069	--	VAR	velocity_sensor_actual_value	UINT32	RO	YES				•		speed units
606B	--	VAR	velocity_demand_value	INT32	RO	YES				•		speed units
606C	--	VAR	velocity_actual_value	INT32	RO	YES				•		speed units
606D	--	VAR	velocity_window	UINT16	RW	YES				•		speed units
606E	--	VAR	velocity_window_time	UINT16	RW	YES				•		ms
606F	--	VAR	velocity_threshold	UINT16	RW	YES				•		speed units
6070	--	VAR	velocity_threshold_time	UINT16	RW	YES				•		ms
607A	--	VAR	target_position	INT32	RW	YES			•			position units
607B	--	ARRAY	position_range_limit	--	--	--			•			--
	0		number_of_entries	UINT8	RW	NO			•			--
	1		min_position_range_limit	INT32	RW	NO			•			position units
	2		max_position_range_limit	INT32	RW	NO			•			position units
607C	--	VAR	home_offset	INT32	RW	YES			•		•	position units
6081	--	VAR	profile_velocity	UINT32	RW	YES			•	•		speed units
6082	--	VAR	end_velocity	UINT32	RW	YES			•			speed units
6083	--	VAR	profile_acceleration	UINT32	RW	YES			•	•		acceleration

												units
6084	--	VAR	profile_deceleration	UINT32	RW	YES			•	•		acceleration units
6085	--	VAR	quick_stop_deceleration	UINT32	RW	YES			•	•		acceleration units
6086	--	VAR	motion_profile_type	INT16	RW	YES			•	•		--
6093	--	ARRAY	position_factor	--	--	--			•		•	--
	0		number_of_entries	UINT32	RW	NO			•		•	--
	1		numerator	UINT32	RW	NO			•		•	--
	2		divisor	UINT32	RW	NO			•		•	--
6094	--	ARRAY	velocity_encoder_factor	--	--	--	•					--
	0		number_of_entries	UINT32	RW	NO	•					--
	1		numerator	UINT32	RW	NO	•					--
	2		divisor	UINT32	RW	NO	•					
6097	--	ARRAY	acceleration_factor	--	--	--	•					--
	0		number_of_entries	UINT32	RW	NO	•					--
	1		numerator	UINT32	RW	NO	•					--
	2		divisor	UINT32	RW	NO	•					--
6098	--	VAR	homing_method	INT8	RW	YES					•	
6099	--	ARRAY	homing_speeds	--	--	--					•	speed units
	0		number_of_entries	UINT8	RW	YES					•	
	1		speed_during_search_for_switch	UINT32	RW	YES					•	speed units
	2		speed_during_search_for_zero	UINT32	RW	YES					•	speed units
609A	--	VAR	homing_acceleration	UINT32	RW	YES					•	acceleration units
60A3	00	VAR	profile_jerk_use	UINT8	RO	NO			•			--
60A4	--	ARRAY	profile_jerk	--	--	--			•			--
	00		number of entries	UINT8	RO	NO			•			--
	01		profile_jerk1	UINT32	RW	NO			•			jerk unit
60C0	--	VAR	Interpolation sub mode select	INT16	RW	NO		•				
60C1	--	ARRAY	Interpolation data record	--	--	--		•				
	0		number_of_entries	UINT8	--	NO		•				
	1		the first parameter of ip function fip(x1, .. xN)	see 60C0h	RW	YES		•				position units
	2		the second parameter of ip function fip(x1, .. xN)		RW	YES		•				position units
60C2	--	RECORD	Interpolation time period	--	--	--		•				
	0		number_of_entries	UINT8	RO	NO		•				
	1		ip time units	UINT8	RW	NO		•				
	2		ip time index	UINT8	RW	NO		•				
60FA	--	VAR	control_effort	INT32	RO	YES			•			
60FC	--	VAR	position_demand_value*	INT32	RO	YES			•			inc
60FD	--	VAR	digital inputs	UINT32	RO	YES						

60FE	--	RECORD	digital outputs	--	--	--						
	0		number_of_entries	UINT8	RO	NO						
	1		pysical_outputs	UINT32								
	2		bit_mask	UINT32								
60FF	--	VAR	target_velocity	UINT32	RW	YES				•		speed units



ESTUN AUTOMATION TECHNOLOGY CO., LTD

Address: 16 Shuige Road, Jiangning Development Zone
Nanjing 211106, P.R.China

Tel: +86-25-58328505/8507

Fax: +86-25-58328504

Web: www.estun.cn

E-mail: export@estun.com



ESTUN

www.estun.cn